



Aircraft Flight Manual

Manufacturer: TOMARK, s.r.o.,
Strojnícka 5, Prešov 08001
Slovak Republic
+421 51 776 44 80
www.tomarkaero.com

Doc. No.: TOM-TC-01-AFM.E

Serial No.: 30790

Registration No.: OM-JGA

Type Certificate No.: EASA.A.606

Model: Viper SD-4 RTC

This AFM is prepared following the recommended structure for flight manuals as defined in GAMA Specification No. 1.

The following documents belong to this aircraft flight manual:

- Operation manual for engine ROTAX 912 S2 / ULS2
- manuals for installed avionics and propeller

The Airplane flight manual must be carried on board the airplane at all times. It should be stored in the aircraft.

Approved by European Aviation Safety Agency through

TCDS No.: EASA.A.606 Issue: 3

Date of approval: 14.DEC 2018

LEFTBLANK INTENTIONALLY

LOG OF REVISIONS

Rev. No. / Date	Revised Pages	Description of Revision
TOM-TC-01-AFM.C	0-1, 0-2, 0-3, 0-4, 4-6, 4-7, 7-8, 4-16, 4-17, 4-18, 7-17, 7-18, 7-24, 7-36, 7-37, 7-38, 7-40	Dual trim Landing light Minor design changes ADxC-DC-58-003 ADxC-DC-58-004
TOM-TC-01-AFM.D	0-1, 0-2, 0-3, 0-4, 4-6, 4-7, 7-8, 4-16, 4-17, 4-18, 7-17, 7-18, 7-24, 7-36, 7-37, 7-38, 7-40	Exhaust silencer Major design change MCA 10061984
TOM-TC-01-AFM.E	Title, 0-1, 0-2, 0-3, 0-4, 0-6, 1-2, 1-3, 1-6, 1-9, 2-3, 2-5, 2-8, 2-9, 2-10, 2-11, 2-12, 2-13, 2-14, 3-1, 3-2, 3-3, 3-4, 3-5, 3-6, 3-7, 3-8, 3-9, 3-10, 3-11, 3-12, 3-13, 3-14, 3-15, 3-16, 4-3, 4-5, 4-6, 4-7, 4-8, 4-9, 4-10, 4-11, 4-12, 4-13, 4-14, 4-15, 4-16, 4-17, 4-18, 5-3, 5-10, 6-4, 6-5, 6-6, 7-5, 7-6, 7-7, 7-8, 7-9, 7-10, 7-12, 7-13, 7-14, 7-15, 7-16, 7-17, 7-18, 7-19, 7-25, 7-26, 7-27, 7-29, 7-30, 7-31, 7-32, 7-33, 7-35, 7-36, 7-37, 7-38, 7-39, 7-40, 7-41, 7-42, 8-12, 8-13, 8-14, 8-15, 8-16, 9-1, 9-2	Basic configuration design update MCA 10068309 Data update Bugs removing Concepts unification Changes to unify AFM format
-	0-1, 0-2, 0-3, 0-4, 0-6, 1-6, 6-4, 6-5, 6-6, 7-5, 9-1	Update of particular aircraft data in compliance with MCA 10062835 REV.2

List of Effective Pages

Section	Page	Date	Section	Page	Date
0	0-1	13.MAR 2020	3	3-3	14.DEC 2018
	0-2	13.MAR 2020		3-4	14.DEC 2018
	0-3	13.MAR 2020		3-5	14.DEC 2018
	0-4	13.MAR 2020		3-6	14.DEC 2018
	0-5	22.MAR 2016		3-7	14.DEC 2018
	0-6	13.MAR 2020		3-8	14.DEC 2018
1				3-9	14.DEC 2018
	1-1	22.MAR 2016		3-10	14.DEC 2018
	1-2	14.DEC 2018		3-11	14.DEC 2018
	1-3	14.DEC 2018		3-12	14.DEC 2018
	1-4	22.MAR 2016		3-13	14.DEC 2018
	1-5	22.MAR 2016		3-14	14.DEC 2018
	1-6	13.MAR 2020		3-15	14.DEC 2018
	1-7	22.MAR 2016		3-16	14.DEC 2018
	1-8	22.MAR 2016		3-17	22.MAR 2016
	1-9	14.DEC 2018		3-18	22.MAR 2016
	1-10	22.MAR 2016	4	4-1	22.MAR 2016
	1-11	22.MAR 2016		4-2	22.MAR 2016
2	1-12	22.MAR 2016		4-3	14.DEC 2018
	2-1	22.MAR 2016		4-4	22.MAR 2016
	2-2	22.MAR 2016		4-5	14.DEC 2018
	2-3	14.DEC 2018		4-6	14.DEC 2018
	2-4	22.MAR 2016		4-7	14.DEC 2018
	2-5	14.DEC 2018		4-8	14.DEC 2018
	2-6	22.MAR 2016		4-9	14.DEC 2018
	2-7	22.MAR 2016		4-10	14.DEC 2018
	2-8	14.DEC 2018		4-11	14.DEC 2018
	2-9	14.DEC 2018		4-12	14.DEC 2018
	2-10	14.DEC 2018		4-13	14.DEC 2018
	2-11	14.DEC 2018		4-14	14.DEC 2018
	2-12	14.DEC 2018		4-15	14.DEC 2018
	2-13	14.DEC 2018		4-16	14.DEC 2018
	2-14	14.DEC 2018		4-17	14.DEC 2018
3	3-1	14.DEC 2018		4-18	14.DEC 2018
	3-2	14.DEC 2018		4-19	22.MAR 2016
				4-20	22.MAR 2016

Section	Page	Date	Section	Page	Date
5	5-1	22.MAR 2016	7	7-21	22.MAR 2016
	5-2	22.MAR 2016		7-22	22.MAR 2016
	5-3	14.DEC 2018		7-23	22.MAR 2016
	5-4	22.MAR 2016		7-24	22.MAR 2016
	5-5	22.MAR 2016		7-25	14.DEC 2018
	5-6	22.MAR 2016		7-26	14.DEC 2018
	5-7	22.MAR 2016		7-27	14.DEC 2018
	5-8	22.MAR 2016		7-28	22.MAR 2016
	5-9	22.MAR 2016		7-29	14.DEC 2018
	5-10	14.DEC 2018		7-30	14.DEC 2018
	5-11	22.MAR 2016		7-31	14.DEC 2018
	5-12	22.MAR 2016		7-32	14.DEC 2018
6	6-1	22.MAR 2016	8	7-33	14.DEC 2018
	6-2	22.MAR 2016		7-34	22.MAR 2016
	6-3	22.MAR 2016		7-35	14.DEC 2018
	6-4	13.MAR 2020		7-36	14.DEC 2018
	6-5	13.MAR 2020		7-37	14.DEC 2018
	6-6	13.MAR 2020		7-38	14.DEC 2018
7	7-1	22.MAR 2016		7-39	14.DEC 2018
	7-2	22.MAR 2016		7-40	14.DEC 2018
	7-3	22.MAR 2016		7-41	14.DEC 2018
	7-4	22.MAR 2016		7-42	14.DEC 2018
	7-5	13.MAR 2020		7-43	22.MAR 2016
	7-6	14.DEC 2018		7-44	22.MAR 2016
	7-7	14.DEC 2018		8-1	22.MAR 2016
	7-8	14.DEC 2018		8-2	22.MAR 2016
	7-9	14.DEC 2018		8-3	22.MAR 2016
	7-10	14.DEC 2018		8-4	22.MAR 2016
	7-11	22.MAR 2016		8-5	22.MAR 2016
	7-12	14.DEC 2018		8-6	22.MAR 2016
	7-13	14.DEC 2018		8-7	22.MAR 2016
	7-14	14.DEC 2018		8-8	22.MAR 2016
	7-15	14.DEC 2018		8-9	22.MAR 2016
	7-16	14.DEC 2018		8-10	22.MAR 2016
	7-17	10.SEP 2019		8-11	22.MAR 2016
	7-18	10.SEP 2019		8-12	14.DEC 2018
	7-19	14.DEC 2018		8-13	14.DEC 2018
	7-20	22.MAR 2016		8-14	14.DEC 2018
				8-15	14.DEC 2018

[illegible]

List of approved sections

Section	Name	Status
1.5	Fuel	Approved (EASA.A.606)
1.6	Oil	Approved (EASA.A.606)
2.	Limitations	Approved (EASA.A.606)
3.	Emergency procedures	Approved (EASA.A.606)
5.	Performance	Approved (EASA.A.606)
6.1	Weight and Balance Chart and CG range	Approved (EASA.A.606)
6.3	Operating Weights & CG determination	Approved (EASA.A.606)

Table of contents

Section 1	General
Section 2	Limitations
Section 3	Emergency Procedures
Section 4	Normal Procedures
Section 5	Performance
Section 6	Weight & Balance / Equipment List
Section 7	Airplane & Systems Descriptions
Section 8	Airplane Handling, Service & Maintenance
Section 9	Supplements

Applicability of the AFM

This TOM-TC-01-AFM.E document is applicable for Viper SD-4 RTC S/N: 29019 aircraft in configuration:

- Model Name Viper SD-4 RTC Basic Variant EASA.A.606 in accordance to TCDS EASA.A.606 Issue: 3
plus
- Additional equipment installed to the Model Name Viper SD-4 RTC Basic Variant EASA.A.606 in accordance to MAJOR CHANGE APPROVAL 10068309:
 - ❖ Landing Light
 - ❖ Dual Trim Controlplus
- Data update of particular Viper SD-4 RTC aircraft in accordance to MINOR CHANGE APPROVAL 10062835 REV.2.

Section 1 GENERAL

Table of Contents

Section 1 GENERAL.....	1
1.1 Introduction	2
1.1.1 Certification Base.....	2
1.1.2 General	2
1.2 Three View Drawing	4
1.3 Engine.....	5
1.4 Propeller	5
1.5 Fuel	6
1.6 Oil.....	6
1.7 Maximum Certificated Weights	6
1.8 Typical Airplane Weights	6
1.9 Specific Loadings.....	7
1.10 Cabin Dimensions.....	7
1.11 Baggage Space	7
1.12 Symbols, Abbreviations and Terminology	7
1.13 Warnings, Cautions and Notes.....	12

1.1 Introduction

In case of occurrences and technical support contact:

TOMARK, s.r.o.,

Strojnícka 5

08001 Prešov

Slovakia

letovaspособilost@tomarkaero.com (occurrences)

sales@tomarkaero.com (technical support)

(+421)51-77480-561

1.1.1 Certification Base

The airplane Viper SD-4 RTC has been approved in accordance with the CS-LSA Amendment1 certification specification of the European Aviation Safety Agency (EASA.A.606).

1.1.2 General

The content of this Aircraft Flight Manual covers all instructions for carrying out a safe flight with the Viper SD-4 RTC airplane.

Each pilot and maintenance technician of the Viper SD-4 RTC airplane is obliged to get acquainted with this Manual.

The Viper SD-4 RTC airplane is operated upon its user's own responsibility.

The Viper SD-4 RTC is designed for sporting and recreational purposes.


The manufacturer of the Viper SD-4 RTC airplane does not bear responsibility for damage to the airplane caused by the use of the airplane in breach of individual provisions of the operation, control or maintenance documentation of the airplane.

THIS MANUAL INCLUDES THE MATERIAL REQUIRED TO BE FURNISHED TO THE PILOT BY THE EUROPEAN AVIATION SAFETY AGENCY REGULATIONS AND ADDITIONAL INFORMATION PROVIDED BY THE MANUFACTURER AND CONSTITUTES THE EASA APPROVED AIRPLANE FLIGHT MANUAL

Further documentation for the operation, control and maintenance of Viper SD-4 RTC refer to latest approved revisions of (supplied by TOMARK):

- TOM-TC-01-AMM.F Viper SD-4 RTC Airplane Maintenance Manual
- OPERATORS MANUAL FOR ROTAX® ENGINE TYPE 912 SERIES
- Operating and Maintenance Manual NEUFORM C3 Series - Ground Adjustable, Rev.4/ 05 March 2018, Part.-No. of this Manual: 9640
- f.u.n.k.e. ATR833-II VHF Communication Transceiver ATR-833 Operation and Installation
- f.u.n.k.e. TRT800H-OLED Mode-S Transponder TRT-800H Operation and Installation
- MODEL E-04 ELT INSTALLATION MANUAL OPERATION MANUAL
- Galaxy GRS Ballistic parachute rescue system Instruction Manual for Assembly and Use
- DYNON AVIONICS SkyView Pilot's User Guide; Document 101321-021, Revision V, For use with firmware version 13.0; August, 2015
- GARMIN aera™ models: 500, 510, 550, 560 GPS manual Pilot's Guide

1.2 Three View Drawing



1.3 Engine

NOTE

For 912 ULS2 variants of the Viper - do not install any Service Bulletin / Service Instruction / Technical Note or other publication released by Rotax without written confirmation by TOMARK.

Number of Engines:	1
Engine Manufacturer:	BRP-Power train
Engine Model Number:	912 S2 / ULS2
Engine type:	Reciprocating
	Normally aspirated
	Geared 2.43:1
	Air cooled cylinders
	Liquid cooled cylinder heads
	4 cylinders

Power Ratings (kW(HP)) / Engine Rotational Speeds (RPM)

(1) Take-off Power	73.5 (100) / 5 800
(2) Maximum Continuous Power	69 (90) / 5 500
(3) Operating Power = 75%	51 (68) / 5 000
Operating Power = 65%	44.6 (60) / 4 800
Operating Power = 55%	38 (50) / 4 300

Engine Speed over 5 500 RPM is restricted to 5 min.

1.4

Propeller

NOTE

Do not install any Service Bulletin / Service Instruction / Technical Note or other publication released by Neuform without written confirmation by TOMARK.

Number of Propellers:	1
Propeller Manufacturer:	Neuform
Propeller Model Name:	CR3-65-(IP)-47-101.6
Number of Blades:	3
Propeller Diameter:	1.65 m

1.5 Fuel

Usable capacity:	90liters
Total capacity of fuel tanks:	100 liters
Fuel specification:	
Knock resistance:	min. RON 95 (min. AKI 91)
European standard (MOGAS):	EN 228 Super, EN 228 Super Plus
AVGAS - unleaded	UL91 (ASTM D7547)
AVGAS - leaded	AVGAS 100 LL (ASTM D910)
US standard	ASTM D4814

1.6 Oil

Description:	For the selection of suitable lubricants refer to SI-912-016 latest edition
Brand:	SHELL Aero Shell Sport Plus 4 (recommended)
Specification:	Min. API SG
Viscosity:	SAE 5W-30 ÷ 15W-50 (depends on oil temperature operation)
Total oil Capacity:	3.5 liters (with oil cooler)
Refill Quantity	3 liters
Oil Quantity Operating Range:	2.5 ÷ 3 liters (in sump; oil level between min. and max. mark)

1.7 Maximum Certificated Weights

Maximum Takeoff Weight	600 kg
Maximum Landing Weight	600 kg
Maximum Baggage Weight	7.5 kg per Compartment 15 kg TOTAL

1.8 Typical Airplane Weights

Empty Weight:	378.6 kg
	Maximum: 405.0 kg
Minimum Crew Weight	55 kg

1.9 Specific Loadings

Wing Loading:	57.4 kg / m ²
Power Loading:	8.16 kg / kW (6 kg / HP)

1.10 Cabin Dimensions

Cabin Width:	1000/1100 mm
Cabin Length:	850/1350 mm
Cabin Height:	950/1050 mm

1.11 Baggage Space

Compartment Width:	420 mm
Compartment Length:	230 mm
Compartment Height:	310 mm
Compartment Volume:	40 dm ³

1.12 Symbols, Abbreviations and Terminology

General Airspeed Terminology and Symbols

AFM	<i>Aircraft Flight Manual</i>
AMM	<i>Aircraft Maintenance Manual</i>
AMO	<i>Approved Maintenance Organization</i>
CAS	<i>Calibrated Airspeed</i> , airspeed corrected by the error of the speed measuring system
GS	<i>Ground Speed</i>
IAS	<i>Indicated Airspeed</i> is the speed of an aircraft as shown in the airspeed indicator when corrected for instrument error.
TAS	<i>True Airspeed</i>
V _A	<i>Maneuvering Speed</i> is the maximum speed at which application of full available aerodynamic control will not overstress the airplane.
V _{FE}	<i>Maximum Flap Extended Speed</i> is the highest speed permissible with wing flaps in a prescribed extended position
V _O	<i>Operating Maneuvering Speed</i> : No full or abrupt single pitch control input above this speed.

V_{NE}	<i>Never Exceed Speed</i> is the speed limit that may not be exceeded at any time
V_S	<i>Stalling Speed</i> or the minimum steady flight speed at which the airplane is controllable.(in clean configuration)
V_{S1}	<i>Stalling Speed</i> or the minimum steady flight speed at which the airplane is controllable in the take-off configuration
V_{S0}	<i>Stalling Speed</i> or the minimum steady flight speed at which the airplane is controllable in the landing configuration
V_X	<i>Best Angle-of-Climb Speed</i> is the airspeed which delivers the greatest gain of altitude in the shortest possible horizontal distance.
V_Y	<i>Best Rate-of-Climb Speed</i> is the airspeed which delivers the greatest gain in altitude in the shortest possible time.

Meteorological Terminology

bar.	<i>bar</i> - unit of pressure, 1 bar = 1 000 mbar
Indicated Pressure Altitude	The number actually read from an altimeter when the barometric subscale has been set to 1013.25 hPa (29.92" Hg).
Pressure Altitude	Altitude measured from standard sea level pressure (1013.25 hPa (29.92" Hg)) by a pressure or barometric altimeter. It is the indicated pressure altitude corrected for position and instrument error.
Station Pressure	An actual atmospheric pressure at field elevation.
Wind	The wind velocities recorded as the headwind or tailwind components of the reported wind.
ISA	<i>International Standard Atmosphere</i> in which <ol style="list-style-type: none"> (1) The air is a dry perfect gas; (2) The temperature at sea level is 15° C (59° F); (3) The pressure at sea level is 1013.25 hPa (29.92" Hg); (4) The temperature gradient from sea level to the altitude at which the temperature is -56,5°C (-69,7°F) is -0,0065° C (-0,0117° F) /m and 0°/m above that altitude.
OAT	<i>Outside Air Temperature</i> is the free air static temperature, obtained either from in flight temperature indications or ground meteorological sources, adjusted for instrument error and compressibility effects.

Power Terminology

Note: *Maximum Power for the combination of the engine and propeller is determined by engine speed“*

Takeoff Power The maximum power permissible for takeoff (may be time limited)

Maximum Continuous Power (MCP) Continuous The maximum power for abnormal or emergency operations.

Maximum Normal Operating Power (MNOP) The maximum power for all normal operations (except Take-off). This power may be the same as Maximum Continuous Power

Cruising Climb Power The power (not to exceed MNOP) recommended to operate the airplane in a cruise climb (a continuous, gradual climb)

Ground Idle Power The power required to run an engine on the ground, as slowly as possible, yet sufficient to ensure satisfactory engine, engine accessory, and airplane operation with a minimum of thrust.

RPM *Revolutions Per Minute*

kW *Kilo-Watt- unit of power, 1 kW = 1 000 W*

HP *Horse-Power - unit of power, 1 HP = 0.735 kW*

Engine Controls and Instruments

THROTTLE LEVER The lever used to control engine power, from the lowest through the highest power, by engine speed.

EGT Gauge The exhaust gas temperature indicator, on piston engine powered airplanes,

Tachometer An instrument that indicates rotational speed of engine as RPM

MAIN SWITCHES “INSTR”, “MASTER”“GENRTR”

Section Switches Switches/Automatic Circuit Breakers to control of electric/electronic onboard equipment

Toggle Switch The section which switches between powering the onboard socket or landing light

Airplane Performance, Flight Planning and Navigation Terminology

Climb Gradient	The demonstrated ratio of the change in height during a portion of a climb, to the horizontal distance traversed in the same time interval
Demonstrated Crosswind Velocity	The demonstrated crosswind velocity is the velocity of the crosswind component for which adequate control of the airplane during takeoff and landing was actually demonstrated during certification tests.
GPS	<i>Global Positioning System</i>
IFR	<i>Instrument Flight Rules</i>
IMC	<i>Instrument Metrological Conditions</i>
RWY	<i>Runway</i>
TWR	<i>Tower</i>
TXY	<i>Taxi Way</i>
VFR	<i>Visual Flight Rules</i>
VMC	<i>Visual Meteorological Conditions</i>

Weight & Balance

Reference Datum	An imaginary vertical plane from which all horizontal distances are measured for balance purposes.
Station	A location along the airplane fuselage usually given in terms of distance from the reference datum.
Arm	The horizontal distance from the reference datum to the centre of gravity (C.G.) of an item
Moment	The product of the weight of item multiplied by its arm. (Moment divided by a constant is used to simplify balance calculations by reducing the number of digits.)
Centre of Gravity (C.G.)	The point at which an airplane would balance if suspended. Its distance from the reference datum is found by dividing the total moment by the total weight of the airplane
C.G. Arm	The arm obtained by adding the airplane's individual moments and dividing the sum by the total weight.
C.G. Limits	The extreme centre of gravity locations within which the airplane must be operated at a given weight
Usable Fuel	Fuel available for flight planning

Unusable Fuel	Fuel remaining after a run out test has been completed in accordance with governmental regulations
Standard Empty Weight	Weight of a standard airplane including unusable fuel, full operating fluids and full oil.
Basic Empty Weight	Standard empty weight plus optional equipment
Payload	Weight of crew and baggage.
Useful Load	Difference between takeoff weight and basic empty weight.
Maximum Takeoff Weight	Maximum weight approved for the start of the take-off run
Maximum Landing Weight	Maximum weight approved for the landing touchdown.
Maximum Zero Fuel Weight	Maximum weight exclusive of usable fuel
MAC	Mean Aerodynamic Chord

1.13 Warnings, Cautions and Notes

Definitions of Warning, Caution and Note used in text of the Aircraft Flight Manual are listed below:

WARNING

It means that the failure to observe the specified procedures will lead to an immediate or substantial decrease of the flight safety.

Information that may prevent danger to life and crew

CAUTION

It means that the failure to observe the specified procedures will lead to a smaller or longer-term decreased flight safety.

Information that may prevent damage to the aircraft and its equipment

NOTE

Focuses attention to a special step, which is not related directly with the flight safety but which is important or unusual.

Information of special importance to the pilot.

Section 2

LIMITATIONS

Table of Contents

Section 2 LIMITATIONS	1
2.1 Airspeed Limitations	2
2.2 Airspeed Indicator Markings	3
2.3 Minimum instruments and equipment list	3
2.4 Power Plant Limitations	4
2.4.1 Propeller Limitations	4
2.4.2 Engine Limitations	4
2.4.3 Power Plant Instruments Markings	5
2.5 Weight Limits	5
2.6 Centre of Gravity Limits	6
2.7 Maneuver Limits	6
2.8 Kinds of Operation Limits.....	6
2.9 Flight Load Factor Limits	6
2.10 Fuel Limitations.....	6
2.11 Outside Air Temperature Limits	7
2.12 System and Equipment Limits	7
2.13 Miscellaneous Limits.....	7
2.14 Placards applicable for basic configuration + Landing Light installed	8

2.1 Airspeed Limitations

Air-Speed	Description	KIAS	KCAS	Remarks
V_{NE}	Never-exceed speed	126	130	Do not exceed this speed in any flight mode!
V_C	Design Cruise speed	102	105	
V_O	operating Maneuvering speed	88	90	No full or abrupt single pitch control input above this speed.
V_A	Design maneuvering speed	88	90	
V_{FE}	Maximum flap extended speed	79	81	It must not be exceeded with extended flaps in any position.
V_S	Stalling speed in clean configuration	49	50	Soiling of the wing, rain and frost on the wing increase the airplane's stalling speed.
V_{S0}	Stalling speed in configuration Flaps – pos. II	43	44	

2.2 Airspeed Indicator Markings

Marking	KIAS value or range	Meaning
White band	43-79	Flap operating range. The lower limit is V_{S0} at the maximum weight in the landing configuration. The upper limit is the maximum flap extended speed.
Green band	49-102	Normal operating range. The lower limit is V_S at the maximum weight and the front-most CG position with retracted flaps. The upper limit is the maximum structural cruising speed.
Yellow band	102-126	Caution range. Turns must be made with care and in calm air.
Red line	126	Never-Exceed speed for any flight mode.

2.3 Minimum instruments and equipment list

The following list defines the equipment that must be installed and operational at start of the flight.

Instrument	optional	required	x-station ¹
Airspeed indicator		X	-200
Altimeter		X	-200
Magnetic compass		X	-250
SkyView - EFIS	X		-200
SkyView - EMS		X	-200
Trim indication (pitch and roll)		X	-200
Safety harness for every used seat		X	-200
Garmin GPS	X		-200
Radio		X	-200
Transponder		X	-200
ELT		X ²	1248

¹ mm aft of wing leading edge

² depending on national regulations

2.4 Power Plant Limitations

2.4.1 Propeller Limitations

Number of Propellers:	1
Propeller Type:	Ground adjustable
Blade angle	22°±0.5° Measured at distance 425 mm from the root of the blade
Propeller Manufacturer:	Neuform
Propeller Model Name:	CR3-65-(IP)- 47-101.6
Number of Blades:	3
Propeller Diameter:	1.65 m
Propeller Speed:	Max.: 2 600 RPM (equals 6320 engine RPM; exceeds engine Max RPM)

2.4.2 Engine Limitations

Number of Engines:	1
Engine Manufacturer:	BRP-Power train
Engine Model Number:	912 S2 / ULS2
Max. Power:	73.5 kW (100 HP)
Speed:	Max.: 5800 RPM Speed over 5 500 RPM is restricted to 5 min. Min.: 1 400 RPM
Engine operation at zero gravity	Max.: 5 second at max. -0,5g
Coolant Temperature:	Max.: 120° C (248° F)
Oil Pressure:	Max.: 7 bar (102 psi); For a short period admissible at cold start Min.: 0,8 bar (12 psi) Below 3 500 RPM
Oil Temperature:	Max.: 130° C (266° F) Min.: 50° C (120° F)
Fuel Pressure:	Max.: 0.50 bar Min.: 0.15 bar
Exhaust Gas Temperature (EGT):	Max.: 880° C (1616° F) /take-off/
Engine Start Operating Temperature:	Max.: 50° C (120° F) / ambient / Min.: -25° C (-16° F) / oil /

2.4.3 Power Plant Instruments Markings

Instrument	Red line Lower limit	Yellow band Warning range	Green band Normal operation	Yellow band Warning range	Red line Upper limit
Tachometer	0÷220 RPM	220÷1350 RPM	1 350÷ 5 500 RPM	5 500÷ 5 800 RPM	5 800÷ 5900 RPM
Manifold Pressure	-----	-----	600÷926 mbar	926÷1 014 mbar	1 014 mbar
Exhaust Gas Temperature	-----	0÷800 °C	800÷850 °C	850÷880 °C	880÷900 °C
Coolant Temperature	-----	50÷75 °C	75÷110 °C	110÷120 °C	120÷135 °C
Oil Temperature	0÷50 °C	50÷90 °C	90÷110 °C	110÷130 °C	130÷150 °C
Oil Pressure	0÷0.8 bar	-----	0.8÷5.0 bar	5.0÷7.0 bar	7.0÷8.0 bar
Fuel Pressure	0.15 bar	-----	0.15÷0.50 bar	-----	0.5÷0,7 bar
Fuel Flow	-----	-----	0÷25 l/h	25÷30 l/h	30÷35 l/h
Ammeter	-15÷-14 A	-14÷-12 A	-12÷+23 A	+23÷+24 A	+24÷+25 A
Voltmeter	10÷11 V	11÷12.4 V	12.4÷14.6 V	14.6÷15.6 V	15.6÷16 V
Fuel Capacity	0÷5 liters	5÷10 liters	10÷45+ liters	-----	-----

2.5 Weight Limits

Maximum Takeoff Weight	600 kg
Maximum Landing Weight	600 kg
Minimum Weight of Crew	55 kg
Maximum Baggage Weight	7.5 kg per Compartment/ 15 kg Total
Maximum Empty Weight	405 kg

2.6 Centre of Gravity Limits

CG range: Forward: 24 %MAC
Aft: 32 %MAC

2.7 Maneuver Limits

Viper SD-4 RTC airplane is designed only for non-aerobatic operation!

Aerobatic flights and intentional spins with the Viper SD - 4 are strictly forbidden.

2.8 Kinds of Operation Limits

Viper SD-4 RTC may only be used for flights during the day, under VMC conditions, according to the day-VFR rules.

Flights in icing conditions, flight into IMC conditions are prohibited.

Intentional spinning and aerobatic maneuvers are prohibited.

Maximum demonstrated components of wind for Take-off and Landing

Cross Max.: 15 kts (7.5 m/s)

Tail Max.: 5 kts (2,5 m/s)

2.9 Flight Load Factor Limits

In normal operations:

Maximum Positive g-load: +4 g

Maximum Negative g-load: -2 g

With Flaps out max pos. g-load +2 g

With Flaps out max neg. g-load 0 g

2.10 Fuel Limitations

Fuel Capacity in Each Fuel Tank: 50 liters

Total Fuel Capacity: 100 liters

Unusable Fuel in Each Tank: 5 liters

Total Usable Fuel Capacity: 90 liters

2.11 Outside Air Temperature Limits

Maximum outside temperature	+40 °C
Minimum outside temperature	-15 °C (at ground)

2.12 System and Equipment Limits

Starter

Starter activation without interruption	Max.: 10 seconds
Cooling period after 10 seconds starter use	Min.: 2 minutes

Ballistic Parachute Rescue System

Allowed never exceed speed KTAS for use V_{NE}	Max.: 170 kts
Temperature range	Max.: +60° C Min.: -40° C

On-board electric socket

Power consumption 12V	Max.: 1 A (12 W)
-----------------------	------------------

2.13 Miscellaneous Limits

Flap position III (40 deg) is only to be used for emergency and precautionary short field landings as described in section 3. At this flap setting, full trimmability is not possible.

Pilot in command seat is the left hand seat.

No smoking on board of Viper SD-4 RTC aircraft.

2.14 Placards applicable for basic configuration + Landing Light installed

Location	Placard
<i>Inside the Cabin</i>	
<i>The Left Instruments Panel</i>	
Above the push button starter	START
Above the generator switch/circuit breaker	GENRTR
Above the master switch/circuit breaker	MASTER
Above the instrument switch/circuit breaker	INSTR
Above left RED annunciator	GENRTR WARNING
Above GREEN annunciator	FUEL PUMP
Above middle RED annunciator	ALARM EMS
Above right RED annunciator	STARTER PROCESS
Above added GREEN annunciator which informing that landing lights is powered ON – added part of joint label	LANDING LIGHT
Above the EFIS screen USB interface connector	USB SkyView ONLY
At the top in the right corner near center panel	KIAS LIMITS
Left at the bottom	↓AFM
Above the Choke control handle	☉CHOKE PULL& HOLD ON
<i>Centre Instrument Panel</i>	
At the top in the center	(Callsign)
At the left side in line with switches/circuit breakers	ON OFF
Above the EMS switch/circuit breaker/	EMS
Above the Inter COMM switch/circuit breaker	INTRCM
Above the COMM Transceiver switch/circuit breaker	RADIO
Above the EFIS switch/circuit breaker	EFIS
Above the Fuel Pump switch/circuit breaker	FUEL PUMP
Above the Start Power switch/circuit breaker	STARTERPOWER

Location	Placard
Above the Flaps switch/circuit breaker	FLAPS
At the left side in line with switches/circuit breakers	ON OFF
<i>Centre Instrument Panel</i>	
Above the Trim switch/circuit breaker	TRIM
Above the GPS Navigation receiver switch/circuit breaker	GPS
Above the Transponder SSR ATC switch/circuit breaker	XPDR
Above the Navigation Lights switch/circuit breaker	NAV LIGHTS
Above the Strobe Lights switch/circuit breaker	STROBE
Above the Socket 12V/1A switch/circuit breaker	SOCKET 12V LANDING LIGHT
Above position of toggle switch	LANDING LIGHT
Above position of blended opening for reserve switch/circuit breaker	RES.
Left at the bottom	Do not exceed MTOM 600kg!
In the center at the bottom	AEROBATICS and intentional spins are PROHIBITED !
Right at the bottom	This aircraft has been approved only for VFR day flights under no icing conditions and must be operated within limitations defined in AFM
<i>Right Instrument Panel</i>	
Above the EMS screen USB interface connector	USB SkyView ONLY
Above the SOCKET 12V (Cigarette Lighter Connector)	SOCKET 12V
Above the Cabin Heating control handle	CABIN HEAT

Location	Placard
Above the Carburetor Heating control handle	CARB. HEAT
Above the Cylinder Heating control handle	CYLINDER AIR
Cylinder Air lever head	PULL ON
Cabin Heat and Carburetor Heat lever heads	PULL CLOSE
<i>Above instrument Panel</i>	
Inside of cockpit on the upper left/right cover of instrument panel	<p>Black bordered orange triangle with pictogram</p> <p>WARNING</p> <p>This aircraft is equipped with ballistically-deployed emergency parachute system</p>
<i>Front part of the center console between the seats</i>	
Under/In back of the THROTTLE LEVER	THROTTLE
Top of the throttle friction control knob THROTTLE FRICTION LOCK	Black bordered white circle with pictogram
Above the AEPS activation handle in the center at the bottom	TO ACTIVATE PARACHUTE PULL HANDLE
On top of the Brake Lever	BRAKE
Behind the FLAPS control panel	FLAPS Position III IS ONLY TO BE USED FOR PRECAUTIONARY AND EMERGENCY SHORT FIELD LANDING
Microphone and headphone sockets console	<div>COPILOT PILOT</div> <div>HEADPHONES MICMIC HEADPHONES</div>
<i>Behind the Seats</i>	
Baggage compartment (2x)	Baggage 7,5 kg
Behind the baggage compartment	NOT FOR BAGGAGE
<i>Canopy Frame</i>	
Left side of the canopy frame nearby lock handle	OPEN - CLOSE (PICTOGRAM)
Right side of the canopy frame nearby lock handle	CLOSE – OPEN (PICTOGRAM)
Informative direction at each air valve on canopy frame	CLOSE ⇄ OPEN




Figure 2-1 Cabin placards preview

Location	Placard
<i>Outer airplane surfaces</i>	
Over the oil dipstick cover located at the right side of the upper part of the engine cowl in front of the canopy edge	RON 424 / SAE10W-40 API min. SG or higher (see also SI-912-016 ch. 3) the latest issue)
The right side of the fuselage in front of the leading edge of the right wing and in front of the lower edge of the edge of the AEPS deployment cover	DANGER - EXPLOSIVE - EGRESS triangle + pictogram
The right side of the fuselage in front of the leading edge of the right wing and in front of the lower edge of the edge of the AEPS deployment cover under the warning triangle	STAY CLEAR with additional information on red bordered rectangle
Fuel tank (edgewise fuselage)	NO STEP
Near the tank filler cap of the fuel tank (2x)	MAX 50L, Usable Fuel 45L, Min RON 95
Ailerons, Flaps, Elevator, Elevator up-float tab, Rudder (trailing edge)	NO PUSH
Flaps (edgewise fuselage)	RED RECTANGLE + RED CROSS + NO STEP (written on red cross)
Under the upper part of the engine cowling at firewall from engine sight above coolant overflow bottle	Conventional ETG based coolant + water Mixing ratio: 1:1 ...
On body of extraction device (between instrument panel and firewall, at right side of the fuselage, under the fuselage skin	DANGER EXPLOSIVE ROCKET triangle + pictogram
The wheel fairing of the front landing gear – at the left side of just above the wheel axis seat	TYRE 120 + 10kPa

Location	Placard
<p>The wheel fairing at the left leg of the main landing gear - at the left side just above the wheel axis seat (1x)</p> <p>The wheel fairing at the right leg of the main landing gear - at the right side just above the wheel axis seat (1x)</p>	<p>TYRE</p> <p>220 + 10kPa</p>
<p>Right side of fuselage near the location of the Fire extinguisher in Baggage compartment</p>	<p>White pictogram of fire extinguisher on red rectangle with rounded corners and white border</p>
<p>Right side of fuselage near the location of the First-aid kit in Baggage compartment</p>	<p>Green cross on green bordered white circle</p>
<p>Right side of fuselage near the location of the ELT in Baggage compartment</p>	<p>Black</p> <p>ELT LOCATED HERE</p> <p>on yellow black bordered triangle</p>
<p>The fuselage (2x, left and right side between wing trailing edge and vertical stabilizer leading edge at the upper half part of the fuselage)</p> <p>The bottom part of the left wing</p>	<p>(Aircraft registration)</p>



Figure 2-2 Outer airplane surface placards preview

Section 3

EMERGENCY PROCEDURES

Table of Contents

Section 3 EMERGENCY PROCEDURES	1
3.1 Airspeeds for Emergency Procedures	3
3.2 Engine Failure	3
3.2.1 During Take-off run	3
3.2.2 After Take-off	3
3.2.3 Engine Failure in-Flight, engine restart	4
3.2.4 Engine shut down after Failure in-Flight	5
3.3 Exceeding of Maximum Admissible Engine Speed	5
3.4 Not possible power setting – THROTTLE LEVER linkage cables failure	5
3.5 Fuel System Failures	5
3.5.1 Fuel Pressure Below Minimum – On Ground	5
3.5.2 Fuel Pressure Over Maximum – On Ground	5
3.5.3 Fuel Pressure Below Minimum – During Flight	6
3.5.4 Fuel Pressure Over maximum – During Flight	6
3.6 Oil System Failures	6
3.6.1 Oil Pressure Below Minimum – On Ground	6
3.6.2 Oil Pressure Over Maximum – On Ground	6
3.6.3 Exceeding of Maximum Admissible Oil Temperature – On Ground	6
3.6.4 Oil Pressure Below Minimum – During Flight	6
3.6.5 Oil Pressure Over Maximum – During Flight	7
3.6.6 Exceeding of Maximum Admissible Oil Temperature – During Flight	7

Emergency procedures

3.6.7	Oil leakage	7
3.7	Cooling System Failures	7
3.7.1	Exceeding of Maximum Admissible Coolant Temperature ..	7
3.8	Propeller Failures During Flight	8
3.9	Glide	8
3.10	Landing Emergencies	8
3.10.1	Emergency Landing without Engine Power	8
3.10.2	Precautionary Landing with Engine Power	9
3.10.3	Approach and Landing with Flaps Retracted	10
3.11	Landing Gear failures	10
3.12	Smoke and Fire	11
3.12.1	Engine Fire During Take-off (On the Ground)	11
3.12.2	Engine Fire After Take-off and During Flight	11
3.12.3	Fire in the cockpit	11
3.13	System Emergencies	12
3.13.1	Electrical system failures	12
3.14	Loss of EMS or EFIS functionality	13
3.15	Loss of Flight Controls	13
3.16	Spin	14
3.17	Vibrations	14
3.18	Activation of the rescue parachute	15
3.19	List of EMS warning alerts	15
3.20	List of EMS caution alerts	18

3.1 Airspeeds for Emergency Procedures

Engine Failure After Take-off:

Flaps UP	64 KIAS
Flaps Down-Position I	64 KIAS
Air Start:	>70 KIAS
Balked Landing:	>53 KIAS
Maximum Glide:	64 KIAS
Landing Without Engine Power:	
Flaps Up	64 KIAS
Flaps Down	64 KIAS

3.2 Engine Failure

3.2.1 During Take-off run

THROTTLE LEVER	IDLE
BRAKE	Brake until STOP
FUEL PUMP	Switch-OFF
FUEL selector	CLOSE
IGNITION	Switch-OFF
Section switches	Switch-OFF
MAIN SWITCHES	Switch-OFF

3.2.2 After Take-off

Airspeed	Maintain 65 KIAS
FUEL PUMP	Switch-OFF
IGNITION	Switch-OFF
FUEL selector	CLOSE
FLAPS	Extend as desire
Carry out an Emergency Landing according to the point 3.10.1	
Instruments	Switch-OFF after landing
Section switches	Switch-OFF
MAIN SWITCHES	Switch-OFF

CAUTION

If the engine fails at low altitudes, carry out landing in the direction of the flight (with diverting, if there are obstacles in the direction of the flight).

3.2.3 Engine Failure in-Flight, engine restart

Airspeed Maintain 70 KIAS

CARB. HEAT Pull (activate)

Landing field Chosen

All unnecessary equipment Switch-OFF

FUEL selector Switch to the tank with more fuel

FUEL PUMP Switch-ON

Fuel Pressure Confirm

IGNITION Switch-OFF than to BOTH

If engine is not wind milling

STARTER POWER Check if it is ON or switch ON

START button Press until engine starts

If starter is inoperative and propeller is not wind milling:

AIRSPEED 115KIAS

Engine is running Switch-ON all necessary equipment

THROTTLE LEVER Adjust

CARB. HEAT Check

Note: The carburettor heat control should never be used in intermediate position. A gradually reducing power might be caused by carburettor icing – this however is not always noticed; therefore carburettor icing must also be considered as potential reason for complete engine shut down.

Note: In case of engine failure maintain speed at best glide and do not reduce speed unnecessary to avoid the propeller stopping.

CAUTION

After starting the engine land as soon as practical.

If you fail starting the engine proceed with emergency landing according to the point 3.10.1

3.2.4 Engine shut down after Failure in-Flight

Airspeed..... Maintain 65 KIAS
 IGNITION..... Switch-OFF
 FUEL PUMP Switch-OFF
 FUEL selector Switch-OFF
 Carry out Emergency Landing according to the point 3.10.1

3.3 Exceeding of Maximum Admissible Engine Speed

THROTTLE LEVER Reduce engine speed

3.4 Not possible power setting – THROTTLE LEVER linkage cables failure

Air speed..... Appropriate to power setting
 Altitude..... Control by switching ignition ON/OFF as required
 Airspeed while engine OFF > 70 KIAS
 Landing As soon as practical

3.5 Fuel System Failures

3.5.1 Fuel Pressure Below Minimum – On Ground

FUEL PUMP ON
 Fuel pressure..... Monitor
 Fuel amount..... Check the fuel quantity in the tanks indicated on the EMS
 FUEL selector Switch to the tank with more fuel
 Engine speed..... If problem persist – stop engine
 Fuel system Check

3.5.2 Fuel Pressure Over Maximum – On Ground

FUEL PUMP ON
 Fuel pressure..... Monitor
 Engine speed..... If problem persist – stop engine
 Fuel system Check

3.5.3 Fuel Pressure Below Minimum – During Flight

FUEL PUMP	ON
Fuel pressure	Monitor
Fuel amount	Check the fuel quantity in the tanks indicated on the EMS
FUEL selector	Switch to the tank with more fuel

3.5.4 Fuel Pressure Over maximum – During Flight

FUEL PUMP	ON
Fuel pressure	Monitor
THROTTLE LEVER	Reduce power

3.6 Oil System Failures

3.6.1 Oil Pressure Below Minimum – On Ground

Engine Speed Stop the engine immediately
Oil system Check

3.6.2 Oil Pressure Over Maximum – On Ground

Engine Speed Stop the engine immediately
Oil system Check

3.6.3 Exceeding of Maximum Admissible Oil Temperature On Ground

Engine Speed Stop the engine immediately
Oil system Check

3.6.4 Oil Pressure Below Minimum – During Flight

THROTTLE LEVER	Reduce engine power setting to the minimum necessary to maintain flight
Oil Pressure	Monitor
Oil Temperature	Monitor
Precautionary Landing	Land as soon as practical according to the point 3.10.2 Prepare for emergency landing according to the point 3.10.1

3.6.5 Oil Pressure Over Maximum – During Flight

THROTTLE LEVER	Reduce engine power setting to the minimum necessary to maintain flight
Oil Pressure	Monitor
Oil Temperature	Monitor
Precautionary Landing	Land as soon as practical according to the point 3.10.2 Prepare for emergency landing according to the point 3.10.1

3.6.6 Exceeding of Maximum Admissible Oil Temperature – During Flight

THROTTLE LEVER	Reduce engine power setting to the minimum necessary to maintain flight
Oil Temperature	Monitor
Oil pressure	Monitor
Precautionary Landing	Land as soon as practical according to the point 3.10.2 Prepare for emergency landing according to the point 3.10.1

3.6.7 Oil leakage

Oil leakage detected	EMS screen - Check oil pressure and oil temperature
Landing	Land as soon as practical – fire hazard

3.7 Cooling System Failures

3.7.1 Exceeding of Maximum Admissible Coolant Temperature

THROTTLE LEVER	Reduce engine power setting to the minimum necessary to maintain flight
Coolant Temperature	Monitor
Oil Pressure	Monitor
Oil Temperature	Monitor
Precautionary Landing	Land as soon as practical according to the point 3.10.2 Prepare for emergency landing according to the point 3.10.1

Emergency procedures**3.8 Propeller Failures During Flight**

This failure is accompanied by strong vibrations. Vibrations of the engine are transmitted to the structure of the entire airplane.

The propeller malfunction can cause significant destruction of propeller and consequently damage to the engine or its attachment to the fuselage.

It can be accompanied by an immediate increase of engine speed over maximum admissible engine speed.

THROTTLE LEVER	Reduce engine power
IGNITION	Switch-OFF if necessary
Airspeed	Reduce until vibrations are within acceptable level.
Section switches	Switch-OFF all not need equipment for flight continuation
Precautionary Landing	Land as soon as practical according to the point 3.10.2 Prepare for emergency landing according to the point 3.10.1

3.9 Glide

Airspeed specified.....	Maintain 64 KIAS
Glide ratio:.....	8:1
Glide range:	1.32 Nm per 1000 ft

3.10 Landing Emergencies**3.10.1 Emergency Landing without Engine Power**

Airspeed	Maintain 64 KIAS
Section switches	Switch-OFF unnecessary for the continuation of the flight
IGNITION	Switch-OFF
FUEL PUMP	Switch-OFF
FUEL selector	Switch-OFF
FLAPS	As appropriate
ELT	Consider Activation

After landing:

Section switches Switch-OFF

MAIN SWITCHES Switch-OFF

3.10.2 Precautionary Landing with Engine Power

Airspeed Adjust to 64 KIAS

Section Switches Switch off all unnecessary equipment

Fly over the ground altitude 500 ft

FLAPS Position I

Traffic pattern altitude 500 ft

FLAPS Position III – for final approach

ELT Consider activation

Short before touch down

FUEL PUMP OFF

FUEL selector OFF

IGNITION OFF

After touch down

BRAKE Brakes; apply full and lock after airplane is stopped

MAIN SWITCHES Switch-OFF

- ➔ Select a suitable area for landing, against the wind direction, if possible.
- ➔ Carry out a fly-over 500 ft above the ground against the wind with flaps at Position I at 64 KIAS and examine thoroughly the condition of the surface (obstacles, quality of the surface).
- ➔ Do a traffic pattern at 500 ft above ground or at an altitude allowed by a decreased cloud base.
- ➔ Extend the flaps into Position I before making the last turn.
- ➔ Do not lose the sight of the selected area.
- ➔ Consider to activate the ELT in case a crash during landing cannot be excluded.
- ➔ Make the final approach in the landing configuration, with increased power of the engine, adjust the approach to touch down right after the passing of the edge of the selected area.
- ➔ Right before touchdown Shut OFF the fuel pump and turn OFF the FUEL selector.
- ➔ Brake after touch down; when the airplane stops, switch off the main switches, and secure the airplane against movement.

3.10.3 Approach and Landing with Flaps Retracted

Approach.....	Perform with engine power with estimation of landing to the RWY threshold
Airspeed	Adjust to 64 KIAS
THROTTLE LEVER	As appropriate
Touchdown	Perform standard touchdown on RWY at the RWY threshold

3.11 Landing Gear failures

The pilot finds out that gear is defective generally in the moment of touchdown.

Airplane tends to veer to the side of the damaged landing gear leg with a strong braking effect on the side of the damaged landing gear leg after touch down on the runway.

However, it can cause extensive damage of individual aircraft parts (landing gear, propeller, engine fairings, engine, wings, fuselage and tail).

Short before touch down:

FLAPS.....	Position III
FUEL PUMP	Switch-OFF
FUEL selector	Switch-OFF
IGNITION	Switch-OFF
Touch down	Accomplish standard touch down at the lowest possible speed

After touch down:

Control	Maintain control, unload nose gear
BRAKE.....	Gentle if possible; apply only to avoid obstacle

After the aircraft is stopped:

FLAPS.....	Retract
Section switches	Switch-OFF
MAIN SWITCHES	Switch-OFF

3.12 Smoke and Fire

3.12.1 Engine Fire During Take-off (On the Ground)

CABIN HEAT Switch-OFF
 FUEL selector CLOSE
 THROTTLE LEVER IDLE
 IGNITION Switch-OFF
 FUEL PUMP Switch-OFF
 BRAKE Brake until STOP
 MAIN SWITCHES Switch-OFF
 Evacuate airplane

3.12.2 Engine Fire After Take-off and During Flight

CABIN HEAT Switch-OFF
 FUEL selector CLOSE
 FUEL PUMP Switch-OFF
 THROTTLE LEVER MAX until engine stops
 IGNITION Switch-OFF
 Equipment unnecessary for
 the continuation of the flight..... Switch-OFF
 Attitude and Ventilation Adjust
 Carry out an Emergency Descent and Landing
 BRAKE Brake until STOP
 MAIN SWITCHES Switch-OFF
 Evacuate airplane

WARNING

Do not start the engine
 after you extinguished the fire on the engine compartment.

3.12.3 Fire in the cockpit

Localize the place of fire
 Extinguish the fire with all available means
 Vent the cabin through the vents

WARNING

If you fail to extinguish the fire carry out the emergency landing.
Land the airplane as soon as possible to inspect for damage.

3.13 System Emergencies**3.13.1 Electrical system failures****Generator failure**

When the **GENRTR WARNING** annunciator on the left instrument panel, located above the Dynon SkyView screen illuminates it informs the pilot about charging failure.

EMS Check charging current and voltage

Recycle generator

Instruments unnecessary for

flight continuation Switch-OFF

Landing Land as soon as possible

CAUTION

After flight with failed generator the battery has to be checked and recharged before the next flight.

Overloading of the current circuit (shortcut)

An overloading of a current circuit is signalled by the failure of the device concerned and the activation of the automatic circuit breaker in the respective section switch.

Section switches Check

The respective section switch... Switch-ON

The device concerned Check the functionality

WARNING

After repeated overloading of a current circuit
do not switch-ON the respective section switch!

There is a risk of electric fire or permanent damage to the current circuit and/or to the device concerned.

3.14 Loss of EMS or EFIS functionality

In case of a SkyView system display failure the remaining operational display switches to a default setting in which only PFD and ENG page are shown. The NAV page is no longer accessible. Resume navigation on traditional means and/or Garmin GPS.

Failure of the ADAHRS can lead to erroneous display of one or several parameters of air data, attitude or heading. Resume flight on outside reference and analogue instrumentation.

In case of EMS data failure all engine related information is lost. Resume flight with airspeeds not exceeding 85KIAS which ensures that engine speed stays within limits.

Land as soon as practical

Continue to the nearest airfield / airport

Follow procedures for Normal Landing described in Chapter 4.10

3.15 Loss of Flight Controls

For all possible flight control failures:

Airplane configuration Do not change the airplane configuration
(flaps should stay where they are)

THROTTLE LEVER Change power setting only gradual

Control Control the airplane by remaining means

ELT Activate ELT

Landing Land as soon as possible

If control is not possible:

IGNITION Switch-OFF

FUEL selector Switch-OFF

Rescue parachute..... Activate (see 3.18)

3.16 Spin

The Viper SD4 can be recovered from an unintentional spin by standard "PARE" (Power/Aileron/Rudder/Elevator) procedure

THROTTLE LEVER	IDLE
AILERONS	Neutral position
RUDDER	Fully push against direction of rotation until rotation stops
ELEVATOR	Release and make a smooth but fast recovery from the dive

Note: *The four recovery initiation actions are performed basically simultaneously. The pull out must be limited to avoid dynamic stall which is noticeable by buffeting. In case of spin recovery, it may happen that the published load factor and V_{FE} is exceeded. The airplane has been proven to withstand such exceedance.*

WARNING

In case of spin recovery the airplane must undergo a specific inspection as prescribed in the maintenance manual

3.17 Vibrations

Vibrations may occur as a consequence of:

1. An adverse flight mode (slipping/skidding, stalling speed)
 - Change the flight mode.
2. A technical fault of the engine or propeller
 - Choose an engine mode in which the vibrations are the lowest (by controlling the engine's RPM and flight speed).
 - Land as soon as possible
3. Carburettor icing
 - Use carburettor heating control.
 - Change the flight level/altitude.
4. Spinning unbalanced landing gear wheels
 - Stop the wheels by pushing the wheel brake. Do not lock the landing brake!
5. Fuel shortage
 - Switch to other fuel (fuller) tank, FUEL PUMP - Switch-ON

IGNITION.....	Switch-OFF
Passenger.....	Advice to brace
ACTIVATION HANDLE.....	PULL hard at least 100 mm
	Force required for firing is approx. 110 N.
ELT	Activate
FUEL selector	Switch-OFF
Devices not necessary needed for further descent	Switch-OFF all
Ground impact	Protect your face and body as possible

CAUTION

The system is designed for the use in the following cases:

- Damage to the airplane after collision with other object
- Loss of the integrity of the airplane's structure
- Loss of the possibility to control the airplane
- Engine failure over a terrain in which it is not possible to land safely
- Pilot's difficulties during the flight that may cause his inability to land normally

3.19 List of EMS warning alerts

Message Displayed in Message Window	Meaning	Recommended Pilot Action
ENGINE MONITOR	(audio only) unspecified alarm	<ul style="list-style-type: none"> • Look at screen
ENGINE SPEED HIGH	Tachometer exceeds 5800 RPM	<ul style="list-style-type: none"> • Reduce RPM by reducing Throttle or airspeed, if possible. • Perform according to emergency checklist 3.3

Message Displayed in Message Window	Meaning	Recommended Pilot Action
CYLINDER HEAD TEMPERATURE HIGH	Cylinder head temperature above 120°C	<ul style="list-style-type: none"> • Reduce engine power • Pull CYLINDER AIR
EXHAUST GAS TEMPERATURE HIGH	Exhaust gas temperature above 880°C	<ul style="list-style-type: none"> • Reduce engine power • Activate (Pull)CHOKE
OIL PRES HIGH	Oil pressure above 7 bar at least 5 seconds after engine start	<ul style="list-style-type: none"> • Reduce engine power • Perform according to emergency checklist 3.6.2 and 3.6.5
OIL PRES LOW	Oil pressure below 0.8 bar	<ul style="list-style-type: none"> • Monitor oil temperature • Perform according to emergency checklist 3.6.1 and 3.6.4
OIL TEMP HIGH	Oil temperature above 130°C	<ul style="list-style-type: none"> • Monitor oil pressure • Perform according to emergency checklist 3.6.3 and 3.6.6
FUEL PRESSURE HIGH	Fuel pressure above 0.5 bar	<ul style="list-style-type: none"> • Switch-OFF electric fuel pump • Monitor fuel pressure
FUEL PRESSURE LOW	Fuel pressure below 0.15 bar	<ul style="list-style-type: none"> • Switch-ON electric fuel pump • Monitor fuel pressure • If problem remains, switch fuel tanks
FUEL FLOW		<ul style="list-style-type: none"> • Turn ON fuel pump • Change fuel tanks • Monitor fuel pressure and fuel flow

Message Displayed in Message Window	Meaning	Recommended Pilot Action
FUEL QUANTITY	Fuel quantity below 5 liters useable in one tank. This warning might occur during a side slip or crosswind landing.	<ul style="list-style-type: none"> • Switch to full tank • Check fuel quantity and refuel as needed. • Consider landing to refuel
VOLTAGE HIGH	System voltage above 15,6 V	<ul style="list-style-type: none"> • Switch-OFF GENERTR • Monitor Voltage and Ammeter • Reduce electrical load • Land as soon as practical
VOLTAGE LOW	System voltage below 11V	<ul style="list-style-type: none"> • Reduce electrical load • Monitor Voltage and Ammeter • Land as soon as practical
ELECTRICAL CURRENT HIGH	Ammeter above +24 A	<ul style="list-style-type: none"> • Switch-OFF GENERTR • Monitor Voltage and Ammeter • Reduce electrical load • Land as soon as practical
ELECTRICAL CURRENT LOW	Ammeter below - 24 A	<ul style="list-style-type: none"> • Reduce electrical load • Monitor Voltage and Ammeter • Land as soon as practical
CHECK CANOPY LATCH	Canopy switches indicate open canopy	<ul style="list-style-type: none"> • Check Canopy locks on both sides.

3.20 List of EMS caution alerts

Message Displayed in Message Window	Meaning
BACKUP BATTERY IN USE	System has switched to SkyView Battery Backup
OTHER DISPLAY OFFLINE	A SkyView Display has failed or is no longer communication via SkyView Network

Section 4

NORMAL PROCEDURES

Table of Contents

Section 4 NORMAL PROCEDURES	1
4.1 Airspeeds for Normal Operations	3
4.2 Pre-flight Inspections	4
4.3 Before Flight	9
4.4 Engine Start	10
4.5 After Engine Start	11
4.6 Taxiing	12
4.6.1 Before Taxiing.....	12
4.6.2 Taxiing	12
4.7 Take-off.....	13
4.7.1 Before Take-off	13
4.7.2 Normal Take-off	14
4.7.3 Short Field Take off	15
4.8 Climb.....	15
4.9 Cruise.....	15
4.10 Descent.....	16
4.11 Approach	16
4.12 Landing	17
4.12.1 Before Landing	17
4.12.2 Balked Landing (GO AROUND)	17
4.12.3 Landing	18
4.12.4 After Landing	18
4.13 Parking and Shutdown.....	18

Normal Procedures

4.14	Safety and Operational Tips	19
4.14.1	Operation Liquids	19
4.14.2	Winter Operation	19

4.1 Airspeeds for Normal Operations

Take-off, Flaps Up

Normal Climb out..... 65 KIAS

Short Field Takeoff, Flaps Up, Speed at 50 ft.... 53 KIAS

En-route Climb, Flaps Up: 65 KIAS

Recommendation: *Pick a speed of 500 fpm climb as it will provide enough cooling and a sufficient cruise speed for a cruise climb.*

Best rate of climb (Vy):

Normal, Sea Level..... 65 KIAS

Normal, 8.000 ft..... 61 KIAS

Best angle of climb (Vx)..... 53 KIAS

Maneuver speed 88KIAS


Approach and Landing

Normal Approach, Flaps Up..... 65 KIAS

Normal Approach, Flaps Position II..... 63 KIAS

Maximum speed for flaps extracting to Position II..... 79 KIAS

4.2 Pre-flight Inspections



- 1 - Cockpit
- 2 - Left side of the fuselage
- 3 - Empennage
- 4 - Right side of the fuselage
- 5 - Right wing
- 6 - Engine compartment
- 7 - Propeller
- 8 - Front landing gear
- 9 - Left wing
- 10 - Main landing gear

Pre-flight inspection must be carried out by the pilot according to the procedure specified below. Identified deficiencies have to be removed before the flight and should be recorded in the aircraft log book.

1. Cockpit:

- Remove cockpit and aircraft covers.
- Open the canopy.
- Check IGNITION is OFF and all section switches are OFF.
- Check the canopy for cleanliness, possible damage, functioning of the canopy locks.
- Check the seat harness.
- Attach loose objects (put them into boxes) or remove them.
- Check the movements of the CONTROL STICK.
- Verify free movement of the THROTTLE LEVER.
- Switch-ON MAIN SWITCHES: MASTER, GENRTR and INSTR.
- Switch-ON section switches: EFIS, EMS, FLAPS, TRIM, FUEL PUMP

GENRTR WARNING ----- Illuminates

ALARM EMS ----- Blinking

FUEL PUMP ----- Illuminates.

- Check functionality of the auxiliary fuel pump – hearing typical sound and check fuel pressure and fuel flow indicated on the respective instruments on EMS screen.
- Switch-OFF section switch: FUEL PUMP
FUEL PUMP ----- Extinguishes.
- Check functionality of trims and trim position indicators. Check visually actual position of trim tabs on EMS screen and compare. Hearing typical sound of trim servo motors. Set trims to neutral positions.
- Check functionality of the flaps at all 4 positions and position indication. Check visually identical actual position of flaps in all position settings. Hearing typical sound of flaps servo motor. Retract (Position 0).
- Switch on section switches: NAV LIGHTS and STROBE.
- Visually check functionality of navigation and strobe lights.
- Switch-OFF section switches: STROBE, NAV LIGHTS, TRIM, FLAPS.
- Switch ON section switch SOCKET 12V / Landing light
- Switch ON Toggle Switch LANDING LIGHT
LANDING LIGHT ----- Illuminates
- Switch OFF section switch LANDING LIGHT

Normal Procedures

LANDING LIGHT ----- Extinguishes

- Switch OFF section switch SOCKET 12V / Landing light
- Check the fuel qty indication (EMS screen, compare to actual filling as visible with removed filler cap).
- Switch-OFF section switches: EFIS, EMS.

ALARM EMS ----- Extinguishes

GENRTR WARNING ----- Extinguishes

- Switch-OFF MAIN SWITCHES: INSTRUMENTS, GENRTR and MASTER.
- All switches must be Switched-OFF.

2. Left side of the fuselage

- Check the fuselage skin, damage to the coating, riveted joints, check the attachment of covers.
- Check fixation of antennas.

3. Empennage

- Check the attachment and skins of the surfaces and riveted joints
- Check free movement of the elevator
- Check play and attachment of trim tabs.
- Check play in the hinge pins of the rudder and elevator hinges.
- Check correct seating of split pins in the rudder and elevator hinges, steering rods and connections.
- Check the static pressure sensor at the top of the vertical stabilizer for possible damage.
- Check mounting of strobe.
- Check tail skid for damage.
- Remove mooring rope and rudder and elevator locks.

4. Right side of the fuselage

- Check the fuselage skin for damage to the coating and riveted joints, check the attachment of the covers and antennas.

5. Right wing

- Check the wing for the integrity of the skin, riveted joints, and attachment of the wing-tip.
- Check flap and aileron hinges and their free movement.
- Check securing of flap and aileron pins.
- Check aileron trim tab and hinges.
- Check visually the quantity of fuel and right locking of the fuel tank closing cap.
- Check fuel drain for water and sediment.

- Check the closing of the fuel tank.
- Check the condition of the navigation light and strobe
- Remove mooring ropes and aileron locks.

NOTE

When the same trim is operated simultaneously in opposition, the trim will not respond, vice-versa when operated simultaneously in the same direction, the trim will continue responding. PIC should be aware that the trim might be modified from the co-pilot seat.

The not responding of trim is visible to pilot/co-pilot on the SkyView screen by stopped movement of trim indicator.

NOTE

Recommend to not fill individual tanks more than 90% of their maximum volume at outside temperature exceeding 25°C in order to avoid excessive spillage due to thermal expansion.

6. Engine compartment

- Demount the upper part of the engine cowl.
- Check the attachment of the engine mount and of the engine.
- Check the electric cable cabling, connector connections.
- Check hoses and their attachment.
- Check the attachment of the cables to the battery and the air filter.
- Check the attachment of the exhaust pipes.
- Check the tightness of the engine, lubrication system, cooling system, oil radiator and cooling radiator (traces of operation fluids), attachment of the high-voltage cables of the sparking plugs.
- Check clear tube between manifold pressure sensor and engine to not have accumulated fuel.
- Check coolant and replenish as required.
- Remove oil tank cover.

WARNING

The propeller must not be turned in the direction opposite to that of its normal rotation.

WARNING

Before manual turning of the propeller, switch OFF IGNITION, BRAKE the wheels, set THROTTLE LEVER to the IDLE position, and check MAIN SWITCHES being switched OFF.

If the ignition is not off, there is a risk of injury.

- Turn the propeller slowly by hand in direction of engine rotation several times to pump oil from the engine into the oil tank. Maintain the compression pressure for a few seconds to let the gas flow via piston rings into crankcase. This process is finished when air is returning back to the oil tank and can be noticed by a gurgle from the open oil tank.
- Check oil level and replenish as required.
- Install oil tank cap back.
- Check the exhaust pipes, cabin heat shroud and muffler for damage, leakage, and overall condition.
- Check the cleanness of the radiator inlets.
- Check the condition of the cushioning rubber band of the front landing gear.
- Mount the upper part of the engine cowl.
- Check the Landing light for cracks.
- Wash the landing light if its surface is covered with dirt.

7. Propeller

- Firm fit of the blades and of all screws.
- Check propeller tips for play. Play of propeller tips should solely originate from the play of the gearbox.
- Check the surface of the propeller blades for damage:
 - minor damage (scratches) to the leading edge surface is accepted. No visual cracks or indents are accepted.
- Check visible parts of the hub - must be free of cracks.

8. Front landing gear

- Check the wheel for symmetry, deformation, play of the wheel fairing and axle nuts locking.
- Check slip mark; the locking of the wheel pin nut and the wear of the tire.
- Check the inflation of the tire (the pressure according to the value on label).

- Check the condition of the grounding cable on the landing gear's leg.

9. Left wing

- Check the wing for the integrity of the skin, riveted joints, attachment of the wing-tip
- Check flap and aileron hinges and their free movement
- Check securing of flap and aileron pins
- Check identical extension of the flaps in all positions
- Check visually the quantity of fuel
- Check fuel drain for water and sediment
- Check the closing of the fuel tank
- Check the condition of the navigation light and strobe
- Remove protective cover of pitot tube. Check the attachment of pitot tube. Check holes throughput and possible damages.
- Remove mooring ropes and aileron locks

10. Main landing gear

- Check the wheels for symmetry, deformation and play of the wheel fairing;
- Check creep marks
- Check the inflation of the tires and their wear;
- Check the surface of the main landing gear legs for cracks
- Check the locking of the wheel pin nuts,
- Check the overall condition of the disk brakes and of the brake tubing.

4.3 Before Flight

Pre-flight inspection	Completed
Luggage	Secured in luggage compartment
ELT Main Switch	Switch to ARM (One step down to Down) When applicable perform ELT check as described in ELT manual.
BRAKE	Apply Full and Lock
Headphones	Plug-in jacks into headset sockets
CONTROL STICK	Check of free movement
Harness	Fasten and tighten
Canopy	Close and lock
AEPS Activation Handle	Take-out Operational Safety Pin

Normal Procedures

4.4 Engine Start

FUEL selector	Position to the tank with the higher quantity of fuel or LEFT
MASTER	Switch-ON
INSTR	Switch-ON
GENRTR	Switch-ON
EMS	Switch-ON
GENRTR WARNING	Illuminates
ALARM EMS	Blinking
EFIS	Switch-ON
STROBE	Switch-ON
FUEL PUMP	Switch-ON
FUEL PUMP	Illuminates
STARTER POWER	Switch-ON
Propeller Area	Clear
IGNITION	Switch to BOTH
CONTROL STICK	Full back

CAUTION

If the airplane is standing on a stony surface,
do not start the engine
– there is a risk of damage to the propeller by sucked in stones.

Cold start

THROTTLE LEVER	IDLE
CHOKE	Pull out and hold
START	Push
STARTER PROCESS	Illuminates
	Release after engine is started
STARTER PROCESS	Extinguishes

Warm/Hot engine start:

THROTTLE LEVER	Advance 2-5 mm
START	Push
STARTER PROCESS	Illuminates
	Release after engine is started
STARTER PROCESS	Extinguishes

CAUTION

If **STARTER PROCESS** after START button releasing remains illuminated switch OFF MASTER switch immediately!
Then switch off remain main switches and all section switches.
There is a risk of starter and engine damage.
Check starter, respective electrical circuits and engine before next engine start attempt.

NOTE

If the engine does not start, repeat the starting not earlier than in 2 minutes, during which the starter will cool off.

4.5 After Engine Start

THROTTLE LEVER	Adjust to achieve smooth running at approx. 2 000 RPM
Oil Pressure	Check
STARTER POWER	Switch-OFF
FUEL PUMP	Switch-OFF
FUEL PUMP	Extinguishes
Fuel Pressure	Check
CHOKE	Release after engine runs uniformly
THROTTLE LEVER	Set 2 000 RPM for 2 min
THROTTLE LEVER	Set 2 500 RPM until oil temperature reached 50° C
ALARM EMS	Extinguishes if everything is OK

CAUTION

The oil pressure must rise within 10 seconds after starting.
Only when the oil reaches a stable pressure, the engine's RPM may be increased.
If the oil is cold, constantly monitor the oil pressure since, because of an increased flow resistance in the suction branch, the oil pressure may drop again.

CAUTION

To avoid acceleration stresses, when starting the engine, set the THROTTLE LEVER to IDLE.

For the same reason, after reducing the throttle, wait for about 3 seconds before increasing the THROTTLE LEVER to achieve constant RPM of the engine.

4.6 Taxiing

4.6.1 Before Taxiing

INTERCOM.....	Switch-ON if necessary
RADIO.....	Switch-ON
FLAPS.....	Switch-ON
TRIM	Switch-ON
GPS.....	Switch-ON
XPDR	Switch-ON
NAV LIGHTS.....	Switch-ON if necessary
SOCKET 12V.....	Switch-ON if necessary
Radio	ON and SET
XPDR	ON and SET
EFIS and EMS	SET (Baro / QNH)
Altimeter.....	SET (QNH)
TRIMs.....	Check functionality and indication
FLAPS.....	Check functionality and retract (Position 0)
On-board devices and equipment.....	Check functionality

4.6.2 Taxiing

BRAKE.....	Release, test
CONTROL STICK.....	Full back
Taxiing speed.....	Adjust

WARNING

It is forbidden to taxi with a partially or fully open canopy.

WARNING

The SkyView Synthetic vision is for situational awareness only.
Maneuvering the aircraft based upon the SVS information is
forbidden

4.7 Take-off

4.7.1 Before Take-off

BRAKE.....	Brake and Lock
Canopy.....	Check - close and lock (EMS)
Harness.....	Check on and tighten belts
Flight Instruments	SET
Engine Instruments.....	Engine parameters: check within limits
CONTROL STICK.....	Full back
THROTTLE LEVER.....	Set 4 000 RPM
IGNITION.....	Switch L and Check Engine Speed
IGNITION.....	Switch BOTH
IGNITION.....	Switch R and Check Engine Speed
IGNITION.....	Switch BOTH and Check Engine Speed
CARB. HEAT	Pull out and check RPM drop (max. 50RPM); push it back in
THROTTLE LEVER.....	MAX, check max RPM (min 5000)
BRAKE.....	Check (hold position)
THROTTLE LEVER.....	IDLE
THROTTLE LEVER.....	Set 2000 RPM
FUEL selector	Position to the tank with the higher quantity of fuel or LEFT
TRIMs	Check neutral positions
AEPS Activation Handle	Check Unlocking

Normal Procedures

CAUTION

Engine RPM drop with only one ignition circuit must not exceed 300 RPM.

Maximum allowable difference of engine speed by use of either circuit L or R is 115 RPM

When testing the ignition circuits

only one ignition circuit may be switched on/off at a time.

No run irregularity or RPM fluctuations may occur during the engine test. The maximum allowed temperatures and pressures must not be exceeded defined values during the engine test.

WARNING

Take-off is forbidden, if:

- The engine runs irregularly;
- Any of the engine parameter is not within limits;
- Insufficient Brake performance
- Aircraft systems working incorrectly
- Crosswind velocity exceeds permitted limits;
- Usable Fuel quantity in the tanks is less than 2x10 liters;

All airspeeds are given for MTOM and ISA conditions.

4.7.2 Normal Take-off

Transponder.....ACS

FUEL PUMPSwitch-ON

FUEL PUMP----- Illuminates

FLAPS.....Position I

BRAKE.....Unlock and Release

THROTTLE LEVERSet Take-off Power

CONTROL STICK - elevator.....Neutral Position. At 30÷35 KIAS pull slightly to lift the nose wheel

Airplane unstuckAt 40÷45 KIAS

ClimbAirspeed 65 KIAS

FLAPS.....Retract at safe altitude

FUEL PUMPSwitch-OFF

FUEL PUMP----- Extinguishes

4.7.3 Short Field Take off

Transponder	Set A+C+S mode
FUEL PUMP	Switch-ON
FUEL PUMP	Illuminates
FLAPS	Position I
THROTTLE LEVER	Set Take-off Power
BRAKE	Unlock and Release
CONTROL STICK - elevator	Neutral Position. At 30÷35 KIAS pull slightly to lift the nose wheel
Airplane unstuck	At 40÷45 KIAS
Climb	Airspeed 53 KIAS
Once cleared the obstacle	Airspeed 65 KIAS
FUEL PUMP	Switch-OFF
FUEL PUMP	Extinguishes

4.8 Climb

Airspeed	Steady 65 KIAS
THROTTLE LEVER	Keep continuous 5 200÷5 500 RPM
Engine Values	Green bands

CAUTION

If the cylinder head temperature or oil temperature and/or coolant temperature approaches or exceeds limits, reduce the climb angle to increase airspeed and possibly return within limits. If readings do not improve, troubleshoot causes other than high power setting at low airspeed.

4.9 Cruise

THROTTLE LEVER	Keep within the cruise range 4 500 ÷ 5 500 RPM, as necessary
Engine Parameters	Green bands
FUEL selector	Position to the tank with the higher quantity of fuel or LEFT

Normal Procedures

Note 1: The fuel system features a return fuel line that ends in the left hand side fuel tank. When flying on the right hand side tank some fuel (approx. 5-10 l/h) is pumped into the left tank. Therefore to maintain fuel symmetry during the flight the time increment on the left fuel tank is more than on the right hand side fuel tank.

Note 2: The fuel quantity indication system is most accurate in horizontal stable flight. During maneuvering the fuel level may be indicated with some time delay.

4.10 Descent

THROTTLE LEVER Keep within the cruise range
4 500 ÷ 5 500 RPM, as necessary

Engine Parameters Keep in limits

NOTE

It is recommended to descend from higher flight levels with engine at increased idle RPM to prevent its excessive cooling.

4.11 Approach

Airspeed 65 KIAS

CARB. HEAT Activation (Pull)

FUEL PUMP Switch-ON

FUEL PUMP Illuminates

FLAPS Position I or II

THROTTLE LEVER Maintain 3000÷3500 RPM

FUEL selector Position to the tank with the higher quantity of fuel or **LEFT**

BRAKE Check released

SOCKET 12V / LANDING LIGHT Switch ON

LANDING LIGHT Switch ON

LANDING LIGHT Illuminates

NOTE

Landing Light is not required to be switched on during landing at all airports. By switching the toggle switch to the LANDING LIGHT position ON-BOARD 12V socket is not usable for charging any connected device. LANDING LIGHT is operable only when section switch SOCKET 12V/LANDING LIGHT is switched to ON position.

4.12 Landing

4.12.1 Before Landing

FLAPS..... Position II
Airspeed..... Decrease to 57 KIAS
THROTTLE LEVER..... IDLE

NOTE

Flap position III is only to be used
for precautionary short field landing

NOTE

When landing in gusty winds, add the amount of wind gusts to the correct approach speed.

4.12.2 Balked Landing (GO AROUND)

THROTTLE LEVER..... Set Take-off Power
CARB. HEAT Deactivation (Push)
Airspeed..... Maintain 53 KIAS
FLAPS Set Position I
Climb..... After reaching stable engine run and
65KIAS
LANDING LIGHT Switch OFF
LANDING LIGHT-----Extinguishes
FLAPS..... Retract at safe altitude

Normal Procedures

4.12.3 Landing

Touchdown Main Wheels fist
 Landing Roll Lower Nose Wheel gently
 BRAKE Minimum required

4.12.4 After Landing

FLAPS Retract
 TRIMs Set neutral position
 CARB HEAT Deactivation (Push)
 Transponder SET to STBY
 FUEL PUMP Switch-OFF
 FUEL PUMP Extinguishes
 LANDING LIGHT Switch OFF
 LANDING LIGHT Extinguishes

4.13 Parking and Shutdown

THROTTLE LEVER IDLE
 BRAKE Apply until airplane stops
 BRAKE Apply FULL and LOCK
 On-board instruments and
 equipment Switch-OFF
 Section switches Switch-OFF except EMS
 Engine Parameters Check, must be within limits
 IGNITION Switch-OFF, remove Key
 ALARM EMS Blinking
 GENRTR WARNING Illuminates
 EMS Switch-OFF
 ALARM EMS Extinguishes
 GENRTR WARNING Extinguishes
 GENRTR Switch-OFF
 INSTR Switch-OFF
 MASTER Switch-OFF
 FUEL selector OFF
 AEPS Activation Handle Take-in Operational Safety and Lock
 ELT Main Switch Switch to OFF (One step up to
 Centre Position)

Aircraft.....	Secure against moving (use chocks)
BRAKE.....	Unlock and release
Canopy	Close and Lock
Left Opening/Closing Lever	Lock

4.14 Safety and Operational Tips

4.14.1 Operation Liquids

The operation is considered to be a winter one when the outside air temperature drops below +5 °C.

Before the winter operation, do the following:

Cooling system

- The cooling system has been filled in the factory by anti-freeze cooling liquid.
- Check the quantity and the freezing point of the anti-freeze liquid.
- Check the tightness of the cooling system.

Fuel system

- Check the fuel before it is filled into the airplane for possible content of water to prevent the possible freezing of the fuel system.
- Check the fuel filter and replace it if necessary.
- Drain sludge from the fuel tanks.

Lubrication system

- During the operation under worsened climatic conditions we recommend to use the engine oil as it is specified in the OPERATORS MANUAL FOR ROTAX® ENGINE TYPE 912 SERIES.

Electric installation

- Check the condition of the battery and recharge it, if necessary
- Clean the battery's terminals
- When parking the airplane outside a hangar and if the outside air temperature drops below 0°C, demount the battery from the airplane and store it in a warm room.

4.14.2 Winter Operation

- When the outside air temperature decreases under + 5 °C, it is recommended to heat the engine by hot air until the oil temperature is 25 °C before starting.

Normal Procedures

- Do the heating through the air inlets, so that the laminate cowling of the engine is not heated directly.
- The temperature of the blown hot air shall not exceed 50 °C.
- Before taxiing or pushing the plane, make sure the brakes are not frozen.

WARNING

Icing from the air humidity forms in the carburettor on the fuel nozzle and on the throttling flap. It leads a loss in the engine's power and a change in the richness of the mixture.

Minimize flight time at flight levels with the ability to create icing. Use carburettor heating to prevent occurrence of this state in such conditions.

Flights into known icing conditions are prohibited!

Section 5

PERFORMANCE

Table of Contents

Section 5 PERFORMANCE	1
5.1 Introduction to Performance and Flight Planning	2
5.1.1 General	2
5.1.2 Conditions for determining flight performance	2
5.1.3 Performance validity	2
5.2 Airspeed Calibration	2
5.3 Stall Speeds	2
5.4 Take-off Distance	3
5.5 Climb Performances	3
5.6 Service Ceiling	5
5.7 Range Profiles	6
5.8 Endurance Profiles	7
5.9 Cruise Speed Profiles	8
5.10 Glide Ratio	8
5.11 True Airspeed Profiles	9
5.12 Landing Distances	10
5.13 Fuel Flow Profiles	11
5.14 Demonstrated Wind Speeds Performance	12

5.1 Introduction to Performance and Flight Planning

5.1.1 General

All values listed in this section are determined for standard ISA condition.

5.1.2 Conditions for determining flight performance

The below-specified performance values apply under the conditions:

- The standard atmosphere at the sea level for a stable flight,
- The calm air,
- The Maximum Take-off Weight 600 kg,

5.1.3 Performance validity

The performance data are specified for a good condition of the airplane, the engine and the propeller and for usual flying techniques.

5.2 Airspeed Calibration

Note: *The calibration factor is 0,973.*

Speed [kts]	V _{S0}	V _{S1}	V _S	V _Y	V _{FE}	V _H	V _C	V _{NE}
KIAS	43	45	49	64	79	100	102	126
KCAS	44	46	50	66	81	103	105	130

5.3 Stall Speeds

Stall speed Flap UP 49 KIAS
Stall Speed Flap I..... 45 KIAS
Stall speed Flap II = normal landing configuration 43 KIAS
Stall Speed Flap III = **only for precautionary short field** 41 KIAS
landing (no normal operation).....

5.4 Take-off Distance

The specified take-off ground roll is specified for level runway

Flaps Position I

Speed over 50ft 63 KIAS

RUNWAY SURFACE	Take-off run distance		Take-off distance over 50 ft (15 m) obstacle	
	m	ft	m	ft
Tarmac/Concrete	241	791	391	1 283
Grass*	275	902	446	1 463

*not tested: AC91-3 suggests that take-off and landing distances of concrete are multiplied with 1.14 for grass. To be conservative the distances over 50ft are also linearly extrapolated.

5.5 Climb Performances

The Climb Performances are specified for 600kg at any altitude and:


Throttle..... Max Power

Flaps Retracted


Best angle of climb speed:..... V_X (SL) = 54 KCAS = 53 KIAS

Best rate of climb speed: V_Y (SL) = 67 KCAS = 65 KIAS


Climb Performance, Flap UP, ISA, 600 kg




Fuel to Climb, ISA, 600 kg TOW



Time to Climb, ISA, 600 kg TOW




Distance to Climb, ISA, 600 kg TOW


5.6 Service Ceiling

Service Ceiling (Approved)..... **15 500 ft**
(4 725 m)

5.7 Range Profiles




The Range is calculated without the effect of wind considered and assumes a take-off and landing at sea level. It further assumes a reserve of 30 min fuel for the selected cruise condition.

5.8 Endurance Profiles


You should consider the flight endurance data only as indicative.

Endurance, ISA, 600 kg



The endurance assumes a take-off and landing at sea level. It further assumes a reserve of 30 min fuel for the selected cruise condition.

5.9 Cruise Speed Profiles



5.10 Glide Ratio


Glide ratios are specified for:

Airspeed64 KIAS

Glide ratio.....1:8

5.11 True Airspeed Profiles

True Airspeed, ISA, 600 kg



5.12 Landing Distances

The landing distances are specified for:


Power at 50ft IDLE

Runway surface see table

Landing distances	Tarmac/Concrete		Grass*	
	m	ft	m	ft
Normal landing Flap II, Speed over 50 ft 57 KIAS				
Landing distance from 50 ft.....	382	1253	451	1480
Landing ground roll distance with braking	210	689	248	814
Precautionary short field landing Flap III, Speed over 50ft 53KIAS				
Landing distance from 50 ft.....	323	1060	381	1250
Landing ground roll distance with braking	176	577	208	682

* not tested: AC91-3 suggests that take-off and landing distances of concrete are multiplied with 1.18 for grass. To be conservative the distances over 50 ft are also linearly extrapolated.

5.13 Fuel Flow Profiles



5.14 Demonstrated Wind Speeds Performance

Maximum demonstrated speed of wind	[kts]
Head wind at airplane operation.....	25
Cross wind for take-off and landing.....	15
Tail wind for take-off and landing.....	5

Section 6

WEIGHT AND BALLANCE

Table of Contents

Section 6 WEIGHT AND BALLANCE.....	1
6.1 Introduction	2
6.2 Weighing records.....	4
6.3 Weight and balance determination for Flight.....	5

6.1 Introduction

This chapter defines the range of loading within which the airplane may be operated safely.

Procedures for weighing, calculation methods to determine limits of loading and lists of equipment available for this airplane are found in the maintenance manual TOM-TC-01-AMM.

The weighing record sheet (chapter 6.2) reflects the actual status of empty mass and empty mass center of gravity at time of last weighing.

The Viper SD-4 RTC reference system for weight and balance is:

Datum: Wing leading edge

For weighing the airplane the relevant weighing stations and data are:

Nose gear: -706 mm aft datum

Main gear: 578 mm aft datum

Length Mean aerodynamic chord (MAC): 1290 mm

The approved CG range is:

**Operational CG range: 309.6 – 412.8 mm aft datum
24% – 32% MAC**

The approved flight center of gravity location is expressed in mm aft of wing leading edge. Conversion to %MAC is by:

$$(\text{Station}_{\text{CG}} / \text{Length}_{\text{MAC}}) * 100\%$$




Figure 6-1 Approved weight and balance envelope

6.2 Weighing records

Date	Empty Weight	CG positions			Note	Signature
10.MAR 2020	378.6 kg	Empty.....	24.09 % @	378.6 kg	The weighing was carried out with engine operation liquids at the levels of respective top lines with unusable fuel.	
		Most forward.....	25.20 % @	498.4 kg		
		Most aft.....	31.99 % @	584.6 kg		
		(Fuel = 26 l)				

6.3 Weight and balance determination for Flight

To calculate the flight mass and center of gravity the following station data must be used:

Occupant	570 mm aft datum
Fuel	201 mm aft datum
Luggage	1248 mm aft datum

Lever arms for loading are calculated in accordance with the datum.

Compliance with permissible loading limits has to be checked prior each flight with the following calculation:

	Mass m [kg]	Center of gravity CG [mm]	Moment M = m*CG [kg*mm]
Empty (incl. unusable fuel)	378,6	300	
+ baggage (max 15 kg)		1248	
+ occupant(s).		570	
	Σm	$\Sigma M / \Sigma m$	ΣM
= flight condition, no fuel			-
+ fuel		201	
	Σm	$\Sigma M / \Sigma m$	ΣM
= flight condition, with fuel permissible	max 600	<u>309.6 – 412.8 mm aft datum</u>	-

Both conditions with and without fuel must fall within the approved envelope (see chapter 6.1).

Weight and Balance

Example calculation (see blue line in Figure 6-1):

	Mass m [kg]	Center of gravity CG [mm]	Moment M = m*CG [kg*mm]
Empty	378,6	311	117744,6
+ baggage	0	1248	0
+ occupant(s)	55	570	31350
	Σ m	Σ M / Σ m	Σ M
= flight condition, no fuel	433,6	343,85	149094,6
+ fuel 90 liter @0.72kg/liter	64,8	201	13024,8
	Σ m	Σ M / Σ m	Σ M
= flight condition, with fuel permissible	498,4 max 600	325,28	162119,4

Section 7

AIRPLANE & SYSTEMS DESCRIPTION

Table of Contents

Section 7 AIRPLANE & SYSTEMS DESCRIPTION	1
7.1 Basic technical specifications of the airplane	3
7.1.1 Basic dimensions	3
7.1.2 Control surfaces	3
7.1.3 Landing gear	4
7.1.4 Power plant	4
7.1.5 Miscellaneous data	5
7.2 Description of the airplane	5
7.2.1 Fuselage	5
7.2.2 Landing gear	5
7.2.3 Wing	6
7.2.4 Empennage	6
7.2.5 Cockpit	6
7.2.6 Control	7
7.2.7 Fuel system	7
7.2.8 Engine lubrication	7
7.2.9 Engine cooling	7
7.2.10 Electrical System	7
7.2.11 Harness	8
7.2.12 Luggage area	8
7.3 Control elements	8
7.3.1 Control stick and rudder	8
7.3.2 Flaps	8

Airplane and Systems Description

7.3.3	Trimming	9
7.3.4	Throttle	10
7.3.5	Carburettor preheating	10
7.3.6	Landing gear brakes	10
7.4	Overview of drain holes and access hatches	11
7.4.1	Drain holes	11
7.4.2	Access hatches	13
7.5	Overview of equipment	15
7.6	Instrument panel and control panels of Viper SD - 4	17
7.6.1	Controls description	17
7.7	Dynon SkyView Display Layout Modes	20
7.7.1	LHS Display Layout Modes	21
7.7.2	RHS Display Layout Modes	22
7.7.3	LHS/RHS display failure	23
7.8	Controls	24
7.8.1	Control stick	24
7.8.2	Flaps	25
7.8.3	Trim	25
7.9	Engine installation	26
7.10	Lubrication system	27
7.11	Engine cooling	29
7.12	Fuel system	31
7.13	Engine electric system	33
7.14	Engine RPM (power) control	34
7.15	Braking system	34
7.16	Pitot-static system	35
7.17	Electric system	36
7.18	Aircraft Emergency Parachute System (AEPS)	42
7.19	Cockpit ventilation and heating	44

7.1 Basic technical specifications of the airplane

7.1.1 Basic dimensions

Wing span	8.34 m
Length	6.40 m
Height.....	2.20 m
Wing area	10.45 m ²
Wing chord.....	1.29 m
Aspect ratio	6.69
Wing platform.....	rectangular
Wing profile	NACA 4415
Sweep angle	0°
Wing twist	0°
Dihedral.....	3°
Incident angle	3°

7.1.2 Control surfaces

Ailerons

Aileron length	0.96 m
Aileron chord.....	0.27 m
Ailerons area.....	0.52 m ²

Flaps

Type of flap	slot
Flap length	2.197 m
Flap depth	0.255 m
Flaps area	1.12 m ²

Horizontal tail surface

Platform.....	rectangle
Span.....	2.800 m
Depth	0.785 m
Area	2.20 m ²
Dihedral.....	0°
Leading edge swap angle.....	0°
Twist.....	0°
Incident angle	-1.5°

Airplane and Systems Description

Elevator

Chord	0.32 m
Span.....	2.60 m
Area.....	0.75 m ²

Vertical tail surface

Platform.....	rectangular
Root chord	1.217 m
End chord.....	0.587 m
Area.....	1.178 m ²
Height.....	1.300 m
Profile	NACA 0010

Rudder

Area.....	0.56 m ²
Leading edge sweep angle.....	35°
Trailing edge sweep angle.....	11°

7.1.3 Landing gear

Track width.....	2.190 mm
Wheel base	1.270 mm
Brakes	Hydraulic, disk on the wheels of the main landing gear The front Wheel is not braked
Cushioning of the main landing gear	By tires and spring type legs
Cushioning of the front wheel	By the tire and rubber bands
Main landing gear Wheel dimensions.....	4.00-6 (Kaspar K-226A-000 6")
Front landing gear Wheel dimensions	4.00-6 (Kaspar K-116A-000 6")

7.1.4 Power plant

Engine	Rotax 912 S2 / ULS2, 100 HP
Maximum take-off power.....	73.5 kW at 5,800 RPM

Propeller	NEUFORM CR3-65-(IP)-47-101.6
Number of blades.....	3
Diameter	1.65 m

7.1.5 Miscellaneous data

Weights

Empty weight of the airplane	378.6 kg
Maximum take-off mass MTOM	600 kg
Fuel tank capacity.....	72 kg (2 x 50 liters)

Rescue system

Type Galaxy High Technology

Type GRS 6/600 SD S-LSA

ELT

Type ACK Technologies

Type E-04 (406 MHz)

7.2 Description of the airplane

Viper SD - 4 is an aerodynamically controlled, single-engine, two-seat, low-wing all-metal airplane with the side-by-side configuration of the seats.

7.2.1 Fuselage

The aircraft's fuselage is made as an all-metal monocoque frame structure, comprising stringers and aluminum alloy skin; the vertical stabilizer is an integral part of the fuselage. The engine compartment is separated from the crew compartment by a steel firewall.

7.2.2 Landing gear

It is tricycle with a nose wheel.

The wheels of the landing gear are equipped with wheel shoes

The wheels of the main landing gears are braked by hydraulic disc brakes. The brakes are controlled centrally by a lever located on the central panel between the pilots' seats.

Nose landing gear

The nose landing gear suspension is provided by a dual rubber band and a sliding tube guided by two sleeves incorporated to the firewall bulkhead. The front landing gear wheel is steerable.

Main landing gear

The main landing gear legs are a composite spring type design with individual spring for right and left hand side.

Airplane and Systems Description

7.2.3 Wing

It is all-metal, of a rectangular platform and a single-spar design, with an auxiliary/rear spar. The wing is equipped with ailerons, slot flaps controlled electrically into three positions and with integral fuel tanks. The right aileron is equipped with an electrically controlled trim tab. The wing tips are equipped with composite wingtip fairings.

7.2.4 Empennage

It consists of a vertical tail surface and a horizontal tail surface at the back end of the fuselage with conventional configuration. The horizontal tail surface is made of a single-piece stabilizer with a right and left elevators, which are interconnected by the control transmission. The elevator is equipped with a trim tab, controlled electrically. The vertical tail surface of a trapeze shape consists of a vertical stabilizer and a rudder with aerodynamically used rudder horn.

7.2.5 Cockpit

The seats are configured side-by-side.

The cockpit is covered by a clear canopy, which ensures very well outside view. The canopy opens up and backwards. The closing of the canopy is a two point one, controlled by two independent levers on the inner sides of the canopy frame, which allow its locking. Visual indication of LOCK/UNLOCK position of both locks is displaying on ENG page of Dynon SkyView EMS screen.

The cockpit is ventilated by the pressure of the flowing air above the instrument panel with a possibility to control the air through valves located on the side of the canopy frame. The canopy is equipped with two ventilation windows.

The cockpit is equipped with two air vents. Two air inlets are located on the left and right side of the fuselage in front of the cockpit (one on each side). The air from air inlets is led to the air showers. The air showers are controllable and they are located in the corners of the instrument panel.

The cockpit is equipped with an on-board 12 V DC electric socket, located on the right instrument panel. The socket can be used for charging of the battery.

7.2.6 Control

It is complete dual control system for elevator, aileron and rudder. The elevator and the ailerons are controlled via control rods and the rudder is controlled via a pair of Bowden cables.

The rudder pedals are adjustable for left and right side individually.

7.2.7 Fuel system

The fuel system comprises two lockable integrated tanks in the wings, equipped with fuel gauge floats and a drain valve, fuel piping, a FUEL selector and a fuel filter (gascolator). FUEL selector operates from which fuel tank the fuel is used. Lift the red knob and turn the selector to required fuel tank. When selecting between left and right fuel tank the lifting of the red knob is not necessary. When closing the fuel system, lift the red knob and turn the selector into OFF position.

Fuel system is equipped with auxiliary electrical fuel pump.

Fuel system sensors provide information about the fuel level in both tanks, the fuel pressure of the fuel supplied to carburetors.

7.2.8 Engine lubrication

The engine lubrication installation is located in the engine compartment below engine covers. It consists of the oil tank, oil pipelines, the oil cooler, the oil thermostat and the oil pump. The oil pump is part of the engine.

Engine lubrication sensors provide information about pressure and temperature of the engine lubricating oil.

7.2.9 Engine cooling

The engine cooling installation is located in the engine compartment below engine covers. It consists of the coolant radiator, the coolant piping, expansion tank with pressure cap and overflow tank. The coolant pump is part of the engine.

Engine cooling system sensors provide information about engine coolant temperature at two locations.

7.2.10 Electrical System

The electrical system of the aircraft is powered by 12 V DC. The main source is the AC generator (alternator) that is part of the engine. It is

Airplane and Systems Description

equipped with rectifier and regulator. The battery 12V/19 Ah is auxiliary and back-up source.

The engine is equipped with a dual ignition unit of a breakerless, capacitor discharge design, which control is provided by a rotary switch located on the left panel of the instrument panel in cockpit.

The engine is equipped with an electric starter, which is controlled from the cabin by STARTER button and section switch/circuit breaker STARTER POWER.

Electrical circuits are switched and fused by three main automatic circuit breakers and respective section switches / circuit breakers.

Signaling of the selected one-off conditions is ensured by lights annunciators based on LEDs, which are located on the left part of the instrument panel in cockpit.

The Landing Light is mounted in dome located between two inlets located in the lower engine cowling.

7.2.11 Harness

In Viper SD - 4 provides a SCHROTH JTISO-C114 approved 3-point static harness restraint system (Type: 4-03-D802xx).

7.2.12 Luggage area

Area for luggage is divided into two storage parts and is integrated into the fuselage. Luggage area is in the cockpit right behind the pilot seats and both its parts are secured by manually operated - open / close roller hard plastic blinds guided in rails over full length.

No luggage allowed on free surface behind.

7.3 Control elements**7.3.1 Control stick and rudder**

Standard control elements - control stick and rudder are used for Viper SD-4 RTC aerodynamic control.

7.3.2 Flaps

The flaps are controlled in four positions electrically, by a lever control, located on the central control panel between the pilots' seats. The signalling of individual positions of the flap lever control is done by a

single LED in the OFF position (retracted) and three yellow LEDs in positions I, II and III (extended).

Before switching the FLAPS section switch from ON to OFF or from OFF to ON, the flaps control lever always must be set to position 0. After switching on (FLAPS = "ON"), the green LED corresponding to position 0 must blink several times and remain illuminate continuously when the flaps are retracted. The change of the position of the flaps between the individual positions I ÷ III is indicated by the blinking of the respective yellow LED and by its continuous illumination after setting the flaps to the required position.

Any rapid blinking of some of indication LEDs indicates a non-standard remote-control mode of the flaps control. The rapid blinking LED indicates the desired position of the control lever required by automat. After the flaps control lever is moved to the desired position, the standard mode of the remote control is restored.

WARNING

If, for any reason, there is a break in the power supply of the flaps remote control during flight, do not manipulate the flaps control lever and keep it in the set position - do not move it. After moving to the OFF position, when the power supply is connected again, the flaps would be retracted, which could be very dangerous especially at low speeds near the speed stall during landing and climbing immediately after take-off, too.

By pushing the lever to the right and pulling it backwards, the pilot extends the flaps into individual positions:

OFF	-	Retracted
I	-	15°
II	-	30°
III	-	40°

7.3.3 Trimming

The control of the elevator's trim tab and the right aileron tab is electric, by buttons located on the pilot and co-pilot control stick grip G-205 type. In case of control stick CS-6 grip type installation the trimming is done by joystick trigger.

Airplane and Systems Description

The trim tabs position indicators of the positions of the trim tabs are displayed on ENG page of Dynon SkyView EMS screen.

NOTE

When the same trim is operated simultaneously in opposition, the trim will not respond, vice-versa when operated simultaneously in the same direction, the trim will continue responding. PIC should be aware that the trim might be modified from the co-pilot seat.

The not responding of trim is visible to pilot/co-pilot on the SkyView screen by stopped movement of trim indicator.

7.3.4 Throttle

Throttle lever is located on the central panel between pilot seats upper to the brake lever. Front position of the lever corresponds to the maximum power. Back position corresponds to the idle rotations.

7.3.5 Carburettor preheating

The heated air is streaming from a heat exchanger to the carburettor through the airbox. The control lever is installed on the right side of the instrument panel.

Note: *The best efficiency of the carburettor heat system is at high power settings and slow airspeed speeds (preferably below 80 KIAS).*

7.3.6 Landing gear brakes

Both wheels of the main landing gear brake simultaneously, without the possibility of independent braking of individual wheels. The hydraulic brake control lever is located on the central control panel between the pilots' seats, under the engine throttle lever. The braking effect on the wheels is actuated by the pushing of the lever downwards. The lever may be locked in the braking position by a push-button on the left side of the braking cylinder bracket.

Care should be taken if wheel rotation is stopped after take-off in order to not unintentionally engage the brake lock.

7.4 Overview of drain holes and access hatches

7.4.1 Drain holes

As the structure design is a riveted aluminum construction several openings and lead thru options for liquid drain and venting are available.

Drain holes are illustrated in figure 7-1.




Figure 7-1 Draining system – fuselage




Figure 7-2 Draining system – bottom rudder fairing




Figure 7-3 Draining system – tail skid aerodynamic fairing




Figure 7-4 Draining system – lower engine cowling

7.4.2 Access hatches

Access hatches are illustrated in figure 7-5 and described below.




Figure 7-5 Access hatches

Airplane and Systems Description

Access hatches

- 1 Covers of the left and right fuel tank mouths, equipped with locks
- 2 Cover of the oil tank mouth (the oil level dipstick)
- 3 Upper engine cowling
- 4 Lower engine cowling
- 5 Wing root cover, left and right
- 6 Fuselage tail cover; it covers root part of the stabilizer and of the vertical stabilizer
- 7 Main landing gear wheel fairings
- 8 Front landing gear wheel fairing
- 9 Cover of the hole for the inspection of the antennas, located in the cockpit behind the seats, on the wall separating the cockpit from the tail part of the fuselage
- 10 Covers of the hole for the inspection of the aileron pull-push rod, located at the bottoms of the right and left wings
- 11 Cover of the hole for the inspection of the aileron pull-push rod, located at the bottoms of the right and left wings
- 12 Cover of the hole for the inspection of the bracket of the flap pull-push rod, located at the bottoms of the left and right wings.
- 13 Cover of the aileron's trim tab servo drive, located on the lower side of the right aileron
- 14 Covers of the holes for the inspection of the bracket of the elevator pull-push rod and Bowden cable, located at the bottom of the fuselage, behind the cockpit
- 15 Cover of the hole for the inspection of the bracket of the elevator pull-push rod and of the Bowden cables are located on both sides of the fuselage's tail, under the stabilizer
- 16 Cover of the elevator trim tab servo drive, located on the lower side of the right half of the elevator
- 17 Cover of the canopy lock located on both sides of the canopy frame above canopy lock
- 18 Cover of the canopy side hinge located on both sides of the canopy frame above the canopy side hinge
- 19 Cover of the canopy central hinge located in the middle of the back part of the canopy frame

7.5 Overview of equipment

Engine:	Engine Rotax 912 S2 / ULS2
Propeller:	NEUFORM CR3-65-(IP)-47-101.6
Engine instruments:	EMS Dynon SkyView (locked screen section) with backup battery
Flight instruments:	Airspeed indicator Winter 7423, 160kts (ETSO) Altimeter Winter 4550, 20 000 ft (ETSO) Magnetic compass CM24 (ETSO) EFIS Dynon SkyView (secondary AIS and ALT indication)
Navigation equipment:	GPS aera 500 Dynon SV-GPS-250 (sensor for SkyView display)
Radio equipment:	Radio f.u.n.k.e. ATR833 (ETSO) Transponder f.u.n.k.e. TRT800H-OLED (including blind encoder) (ETSO)
Antenna system:	Antenna VHF Comm CI-121 (ETSO) Antenna XPDR AV-74 Antenna GPS Garmin Antenna GPS Dynon
Electric equipment:	Battery VARTA 519901017 (12V/19Ah) Generator (part of the engine) Main on-board network switches Section switches/circuit breakers Annunciators Navigation/Strobe lights 2 x Stick Grip G205 or CS-6 Landing light
Fuel installation:	Two wing fuel tanks with the total capacity 100 liters Two fuel gauge floats Drain valves Fuel valve (selector) ANDAIR FS20b3-B r2 Fuel filter (gascolator) Main fuel pump (part of the engine) Auxiliary electric fuel pump (Pierburg 7.221440.51) Fuel piping Fuel pressure sensor Fuel flow sensor Two carburetors

Airplane and Systems Description

Oil installation:

Oil tank (all Rotax)
Oil filter
Oil radiator
Oil thermostat
Oil pump (part of the engine)
Oil tubing
Oil pressure sensor
Oil temperature sensor

Cooling system:

Cooling liquid collector (all Rotax)
Radiator
Cooler thermostat
Expansion tank
Spill tank
Cooler pump (part of the engine)
Cooler tubing
Cooler temperature sensors (2 pieces)

**Airframe control
instruments:**

UFA-900L flaps servo system
Double controlled two-axis electric trim

Rescue system:

Galaxy High Technology GRS6/600 SD S-LSA

7.6 Instrument panel and control panels of Viper SD-4 RTC

7.6.1 Controls description

The instrument panel consists of a composite frame and three panels on which instruments and controls are located.

The left panel contains: the IGNITION control switch, the engine START button, Main Switches (MASTER, INSTR, GENRTR), the battery charging warning light (GENRTR WARNING), the EMS alarm light (ALARM EMS), the fuel pump control light (power on - FUEL PUMP), the starter control light (power on - STARTER POWER), the landing light control light (power on - LNDG LIGHT), flight instruments (primary barometric Airspeed Indicator and Altimeter, as secondary instrument EFIS (Dynon SkyView), the USB communication interface of the Dynon SkyView and the air showers located at the bottom edge of the left instrument panel. the CHOKE control lever button is located under the left panel.

The central panel contains: radio instruments (COMM radio and XPDR), GPS map indicator and section switches/circuit breakers. The magnetic compass is mounted above the central panel.

The right panel contains: the intercom control panel, the ELT remote control panel, the EMS (Dynon SkyView) instrument for monitoring of the engine and airframe parameters, the airbox control lever button (CARB HEAT), the cylinder air cooling stream control lever button (CYLINDER AIR), the cockpit heating control lever button (CABIN HEAT), the on-board electric socket, the USB communication interface of the Dynon SkyView and the air shower.

The horizontal control panel between the seats contains the engine THROTTLE LEVER + Throttle friction Control rotary knob, the hydraulic BRAKES control lever, the AEPS activation handle the FUEL selector and the FLAPs control.

Both control stick grips contain trim control buttons and push-to-talk button. There are possible two options of stick grip:

- G-205 (Ray Allen)
- or CS-6 (Tosten).

The control panel located between the pilots' seats, at its back, contains sockets to connect headset cable plugs.




Figure 7-6 Controls location

Table 7-1 Controls

1	Control Stick (2x)
2	Rudder Pedals (2x)
3	FLAPs Control
4	TRIM Control Buttons/Joysticks
5	FUEL Selector
6	Engine THROTTLE + Friction Control Knob
7	CHOKE Control lever button
8	BRAKE Lever
9	Air Showers
10	IGNITION Switch
11	Engine START Button
12	MASTER Main Switch + INSTR Main Switch
13	GENRTR Main Switch
14	Warning/ Annunciator Lights
15	Section Switches
16	EMS Screen / Control - Dynon SkyView
17	EFIS Screen / Control - Dynon SkyView
18	Altitude Indicator
19	Airspeed Indicator
20	Magnetic Compass
21	Intercom Control Panel
22	Communication Transceiver Control Panel
23	Headset Socket
24	Push-to-Talk Button
25	ATC SSR Transponder Control Panel
26	GPS Map Indicator aera 500
27	ELT Remote Control panel
28	On-Board 12V Electric Socket
29	CARB HEAT Control lever button
30	CYLINDER AIR Control lever button
31	CABIN HEAT Control lever button
32	AEPS Activation Handle
33	USB Data Socket (2x – EFIS, EMS)

7.7 Dynon SkyView Display Layout Modes

WARNING

The SkyView Synthetic vision is for situational awareness only. Manoeuvring the aircraft based upon the synthetic vision information is forbidden.


NOTE

Firmware updates are configuration changes and need written approval by TOMARK. According data must be requested and will be provided by TOMARK only.

Exchange, repair or maintenance of the SkyView System must be performed via TOMARK as Dynon will not provide EASA Form 1 or equivalent certificates for approved installation.


7.7.1 LHS Display Layout Modes

Primary the GPS data is not displayed on the LHS display. It can be switched on manually by pressing MAP button in Layout mode selection. Respectively after pressing Layout button will allow such display variations:




7.7.2 RHS Display Layout Modes

Primary only engine values are displayed on the RHS. Option to switch on Flight information and GPS data is possible. In layout menu switch on PFD or MAP and such display variations are possible:



7.7.3 LHS/RHS display failure

In case of one of the displays failure such display scenarios are available:



7.8 Controls

7.8.1 Control stick

The airplane is equipped with dual primary controls. The control sticks control the ailerons and the elevator. The foot control pedals control the rudder and the front landing gear wheel.

The transmission of control to the ailerons and to the elevator is secured by pull-push rods. The transmission of control to the rudder is secured by a pair of Bowden cables.

The control surfaces do not foresee a mass balance according to the current version analysis. The rudder horn is only aerodynamically used.




Figure 7-7 Flight control diagram

7.8.2 Flaps

Flaps are controlled electrically by a lever control located on the panel between the pilots' seats. The position of the flaps is indicated by LED diodes. The electric actuator drives a common torsion tube extending/retracting left and right hand side symmetrically.

7.8.3 Trim

The control of the elevator's trim tab and the right aileron's trim tab is electric, by trim buttons, located on both control sticks. The indicator of the position of the elevator trim tab is shown on BOTH Dynon SkyView instruments within EMS panel.

Table 7-2 Control surface deflections

Aileron deflection angle	up $+27^{\circ} \pm 1^{\circ}$		down $-16^{\circ} \pm 1^{\circ}$	
Elevator deflection angle	up $+25^{\circ} \pm 1^{\circ}$		down $-20^{\circ} \pm 1^{\circ}$	
Flap deflection angle	$0^{\circ} \pm 2^{\circ}$	$15^{\circ} \pm 2^{\circ}$	$30^{\circ} \pm 2^{\circ}$	$40^{\circ} \pm 2^{\circ}$ Not used for normal landing
Rudder deflection angle	left $+30^{\circ} \pm 1^{\circ}$		right $-30^{\circ} \pm 1^{\circ}$	
Elevator's trim tab deflection angle	up $+21^{\circ} \pm 2^{\circ}$		down $-33^{\circ} \pm 2^{\circ}$	
Aileron's trim tab deflection angle	up $+28^{\circ} \pm 2^{\circ}$		down $-28^{\circ} \pm 2^{\circ}$	

7.9 Engine installation




Figure 7-8 Engine unit and airbox air flow

The airbox is fed by cold air leaded from inlet located at the right front side of the upper engine cowling. Warm air is taken from the engine compartment by a tube located at back side of engine between engine and firewall whose inlet opening is located near the chamber of exhaust gas silencer. The air filter is located in the airbox on input to the air box. A carburettor heating function is provided by mixing the warm air and cold air in airbox. The air is guided by hoses from the airbox into the carburetors.




Figure 7-9 Engine unit

NOTE

DO NOT block left inlet (in flight direction).

7.10 Lubrication system

The lubrication system is part of the Rotax 912 S2 / ULS2 engine, which is equipped with lubrication with a crankcase with a built-in reduction valve and an oil pressure sensor.

Oil tank

It is located in the engine compartment on the firewall; it is metal, equipped with an oil level gauge.

More information about choosing the right oil can be found in the valid issue of the Rotax Service Letter SL-912-016.

Oil gear pump

It is driven by the camshaft. It is part of the engine.




Figure 7-10 Lubrication system diagram

The oil is sucked in by the pump through the oil radiator from the oil tank and it is pushed through the oil filter into individual lubricated points. The oil from lubricated points gets to the bottom of the crankcase and from there it is pushed by the pistons' pushes into the oil tank.

Oil radiator

It is located at the front of the engine compartment under the reduction gearbox.

Oil filter

It is located on the left side of the engine, below the reduction gearbox.

Oil system ventilation

The ventilation of the oil system is provided by an outlet on the oil tank and led through the bottom engine cowling under the engine compartment.

Thermostat

It is used for regulation of oil temperature and it is located above the engine.

Oil system sensors

Rotax 912 S2 / ULS2 engine oil system of Viper SD-4 RTC aircraft contents two sensors:

- oil pressure sensor
- oil temperature sensor.

Electric signals from sensors are led by cable to Dynon EMS system. Oil pressure and oil temperature are displayed on ENG page of Dynon SkyView EMS screen.


7.11 Engine cooling

Figure 7-11 Cooling system diagram

The cooling of the ROTAX 912 S2 / ULS2 engine is done by liquid-cooled cylinder heads and by air-cooled cylinders of the engine. The liquid cooling of the valve heads is made by a closed circuit with an expansion and overflow tank.

Pump

It is part of the engine and it is located on the rear bottom part of the engine. It is driven by the camshaft.

Airplane and Systems Description

Radiator

It is located at the bottom of the engine compartment, in front of the front landing gear leg.

Collector and expansion tank

They are located in the engine compartment above the engine. The expansion tank is on the firewall and it is plastic.

Overflow tank

The overflow tank is located on the firewall and it is plastic.

Thermostat

Thermostat is located at the left side under airbox chamber. Thermostat is connected into coolant hose that feeds the coolant from expansion tank to radiator.

Cooling liquid

The cooling system has been filled in the factory by a special undiluted cooling liquid Sheron Antifreeze G12++.

More information about choosing the right cooling liquid can be found in the valid issue of the Rotax Service Letter SL-912-016.

The cooling liquid is pumped by the pump driven by the camshaft from the radiator to individual cylinder heads. The liquid is taken from the cylinder heads into a collector. The expansion tank is closed by a plug with a pressure and non-return valve. When the liquid heats up and increases its volume, it opens the overpressure valve and flows into a transparent overflow tank. After the liquid is cooled, it is sucked back into the cooling circuit.

Cooling system sensors

Cooling system contains two coolant temperature sensors. Readings are taken on measuring point at hottest cylinder head (depending on installation) The temperature sensors are located on cylinder head No. 2 and No. 3. Electric signals from sensors are led by cables to Dynon EMS system and temperature of coolant for two readings is displayed on ENG page of Dynon SkyView EMS screen.

7.12 Fuel system

Fuel tanks

They are integrated in the airplane's wings and equipped with drain valves and floats sensing the fuel level.

Fuel tanks are equipped with fuel gauges. Electric signals from sensors of fuel gauges are led by cables to Dynon system and readings of fuel quantity for two fuel tanks are indicated on EMS screen.

Recommend to not fill individual tanks more than 90% of their maximum volume at outside temperature exceeding 25°C in order to avoid excessive spillage due to thermal expansion.

More information about choosing the right fuel can be found in the valid issue of the Rotax Service Letter SL-912-016.

Main fuel pump

The fuel pump, which is part of the engine's equipment, secures the supply of fuel into the engine.

Electrical fuel pump

The second fuel pump supports the fuel flow. The fuel pump indication light at the panel only indicates the electrical power supply of the fuel pump. Monitor the fuel pressure indication on the EMS to confirm working order of the electrical fuel pump.

After switching off the fuel pump, fuel pressure will drop for a few seconds, until the fuel pressure is normalized again. Monitor fuel pressure on the EMS after switching OFF the electric fuel pump.

Fuel filter

Part of the fuel system is fuel filter (gascolator "classic style" 10580 by ACS Products Co.). It is located in the engine compartment on the fuel inlet hose at the firewall.

FUEL selector

It allows switching the fuel take from the left or right fuel tanks. If necessary, it allows closing the supply of fuel into the engine. It is located on the panel between the pilot seats. For engine start always choose the fuel tank with higher volume of fuel. If both are full, use the left tank. The FUEL selector does not co-switch the return line.

Airplane and Systems Description

Fuel system sensors

Rotax 912 S2 / ULS2 engine fuel system of Viper SD-4 RTC aircraft contents these sensors:

- 2 x fuel gauge (1 x each fuel tank)
- Fuel pressure sensor
- Fuel flow sensor

Electric signals from sensors are led by cable to Dynon EMS system. All fuel data are displayed on ENG page of Dynon SkyView EMS screen.




Figure 7-12 Fuel system diagram

7.14 Engine RPM (power) control

A throttle lever and a choke lever are used for the control of the engine's power. The engine throttle lever is located on the panel between the pilot seats, above the brake lever and it controls the throttle plates of the two carburetors.

The choke control allows starting of a cold engine and it is located on horizontal control panel between the seats. To switch on it needs to be pulled and held for required time till engine runs uniformly.

7.15 Braking system

The brakes of the main landing gear are single-circuit, disc friction ones, controlled hydraulically. The system is provided by Kaspar.




Figure 7-14 Braking system diagram

Brake control

They are controlled by pressing downwards on the brake lever, located below the engine throttle lever on the panel between pilot seats.

Both wheels of the main landing gear brake simultaneously, without the possibility of braking individual wheels.

NOTE

If brake power is not sufficient to keep the wheels from rolling at full throttle on a level hard surface the brake must be serviced.

Brake Lock

For the locking of the brake lever in the braked position there is a button located on the left side of the brake cylinder bracket. To release the wheel brake, push the brake lever downwards; the locking pin will release the brake from the locked position.

NOTE

Do not park the aircraft with brake locking!

Make use of wheel chocks.

The parking brake power in locked position varies with brake pad wear and brake fluid level. Monitor movement of the aircraft during high power run ups or engine checks. Additional braking might be necessary to prevent the aircraft from moving.

7.16 Pitot-static system

The Pitot-tube is located at the bottom of the left wing.

The total pressure from the Pitot-tube is fed to the ADAHRS and to the barometric airspeed indicator.

The angle of attack (AOA) pressure is fed to the ADAHRS.

The static pressure is sensed by a static pressure sensor mounted at the top of the vertical stabilizer. The static pressure is fed to the

Airplane and Systems Description

ADAHRS, to the analogue airspeed indicator, to the analogue altimeter and to the blind altimeter of the transponder.




Figure7-15 Pitot-static diagram

Barometric and heading data are transmitted from ADARS to the EFIS and EMS in digital form via Data Bus.

7.17 Electric system

The system use 12V DC. It is supplied by an engine built-in AC generator with a rectifier (12V / 22A DC).

Battery

The battery (VARTA) is an auxiliary source of electric energy, located in the engine compartment on the firewall. It is accessible after the removal of the upper engine cowling.

Main switches

They switch and safeguard section switches that connect individual circles to on-board network.

Engine ignition

The capacitor, contact-free ignition is controlled by a switch-box on the left instrument panel. The ignition is part of a generator located at the back of the engine's body.

Starter

The starting circuit is controlled by the starter button, located on the left instrument panel.

Signalling

A regulator/generator failure is signalled by a red warning light located on the left instrument panel.

Trim

The control of the elevator's trim tab and the right aileron's trim tab is electric, by trim buttons or joysticks, located on both control sticks. Indicators of positions of both trim tabs are displayed on ENG page of Dynon SkyView EMS screen.

Flaps

They are controlled by a lever electric controller, located on the central panel between the pilot seats. Part of the controller is a LED indicator of the position of the flaps.

If the flap lever does not match the flap position while engaging the flap section switch, it will not reset any flap position, unless the lever has been positioned in the matching flap lever position.

A flashing LED of the flap position indication signals that the flap control unit has been power cycled. In this condition the flap must be moved to another position and back.

Radio

The transmission function is controlled by a push-to-talk switch on the control stick of the commander's seat and by a push-to-talk switch on the control stick of the co-pilot seat.

Landing Light

Landing light is used for better visibility of the airplane while approaching on the airport. It is supplied by generator when toggle

Airplane and Systems Description

switch SOCKET 12V / LANDING LIGHT is switched to the LANDING LIGHT position. Before switching the toggle switch to LANDING LIGHT position, the SOCKET 12V / LANDING LIGHT section switch must be switched ON.

Electric current protection

The electric system consists of electric circuits protected by circuit-breakers and the main 125 A melting fuse.

Table 7-3 Current circuits protected by circuit breakers:

Section switch / Circuit	Name of circuit	Current protection
MAIN CIRCUIT BREAKERS		
1	MASTER	60 A circuit breaker
2	INSTR	30 A circuit breaker
3	GENRTR	2 x 30 A circuit breaker
SECTION CIRCUIT BREAKERS		
1	EMS, Warning Lights, Oil Pressure Sensor, Voltmeter,	4 A circuit breaker
2	INTRCM	1 A circuit breaker
3	RADIO	4 A circuit breaker
4	EFIS	5 A circuit breaker
5	FUEL PUMP	3 A circuit breaker
6	STARTER POWER	4 A circuit breaker
7	FLAPS	5 A circuit breaker
8	TRIM	1 A circuit breaker
9	GPS	3 A circuit breaker
10	XPDR	2 A circuit breaker
11	NAV LIGHTS	3 A circuit breaker
12	STROBE	5 A circuit breaker
13	SOCKET 12V / LANDING LIGHT	1 A circuit breaker
14	LANDING LIGHT	Toggle switch
MELTING FUSES ON THE FIREWALL		
1	Regulator input current fuse	25 A melting fuse
2	Charging indicator	1 A melting fuse
3	Ammeter shunt fuse	1 A melting fuse
4	Ammeter shunt fuse	1 A melting fuse
5	Generator fuse	2 x 30 A melting fuse
6	Battery fuse	125A melting fuse
MELTING FUSES BEHIND THE INSTRUMENT PANEL		
1	Rheostat/Connection box	0,5 A melting fuse




Figure 7-16 On-board electric power net




Figure 7-17 Avionics instrument interconnection

7.18 Aircraft Emergency Parachute System (AEPS)

The aircraft is equipped with an AEPS manufactured by Galaxy High Technology and is of GRS 6/600 SD S-LSA type.

The ballistic launching (rocket) and the parachute are installed between the instrument panel and firewall. The AEPS Activation Handle is located under left panel of instrument panel.

The attachments of the parachute to the aircraft are located one at the upper end of the nose gear strut close to the interface to the firewall and fuselage frame/beams. The other two are located at each side of the fuselage next to the landing gear strut interface.




Figure 7-18 AEPS attachments points diagram



Figure 7-19 AEPS rocket



Figure 7-20 AEPS canopy container with packed chute

7.19 Cockpit ventilation and heating

The ventilation of the cockpit of Viper SD-4 RTC is designed as a ram pressure one.

The air entering through the inlets located on the sides of the cockpit is directed by plastic tubes above the instrument panel to ensure the blowing of the air against the canopy, which will prevent moisture condensation on it and to two air showers located on left and right instrument panels.

Canopy glass ventilation is supplied by two inlets located on the both sides of the back side of the canopy frame. The airflow is led to outlets located on the front part of the cabin frame and is controllable by two manually controlled vents located at the sides of canopy frame

The canopy is equipped with ventilation windows on the sides.




Figure 7-21 Ventilation scheme diagram

1. Cockpit air inlets
2. Blow holes above the instrument panel
3. Air showers located on left and right instrument panels
4. Manually controlled valves
5. Air inlets for canopy ventilation
6. Ventilation windows

The heating of the cockpit is provided by collecting warm air from about the exhaust area. This heat is directed by a rubber hose via a firewall to the cockpit. It is controllable via a control button located on the right side of the instrument panel.

Section 8

HANDLING, SERVICE & MAINTENANCE

Table of Contents

Section 8 HANDLING, SERVICE & MAINTENANCE	1
8.1 Ground handling	3
8.1.1 Anchoring - parking of the airplane.....	3
8.1.2 Towing of the airplane	4
8.1.3 Jacking.....	4
8.2 Cleaning and Care.....	5
8.2.1 Cleaning of the canopy	5
8.2.2 Cleaning of coated parts.....	5
8.2.3 Cleaning of the interior.....	5
8.2.4 Care for the landing gear	6
8.2.5 Care for the propeller.....	6
8.3 Servicing operating fluids.....	7
8.3.1 Filling and draining of fuel.....	7
8.3.2 Filling of oil	8
8.3.3 Filling of coolant.....	9
8.3.4 Brake fluid.....	9
8.4 Maintenance of the battery	10
8.5 Break in operation.....	10
8.5.1 Engine.....	10
8.5.2 Propeller.....	11
8.6 Inspections.....	11
8.6.1 Airframe	11
8.6.2 Rotax 912 S2 / ULS2 engine	12

8.6.3	Propeller NEUFORM	13
8.7	Maintenance of instruments and devices	14
8.8	Identification of causes of faults and their elimination	14
8.8.1	Engine	14
8.8.2	Propeller	15
8.9	Spare parts	16

8.1 Ground handling

CAUTION

It is prohibited to pull or push the airplane by propeller blades, flaps, ailerons or tail surfaces.

8.1.1 Anchoring - parking of the airplane

The airplane has to be anchored if it is parked outside a hangar in an open area, or if there is a strong wind or a storm.

- Main switches OFF
- Section switches OFF
- Turn switch keys OFF
- Fuel selector OFF.
- Lock the control surfaces with control surface locks or fix stick in the PULL position with the seat belts.
- Cover the canopy with a cloth.
- Anchor the airplane with ropes or chains at anchoring points.
- Insert covers on both Pitot-static and static sensor
- Insert control surface blocks




Figure 8-1 Anchoring of the airplane

CAUTION

Do not expose the cockpit to intense sunlight. There is a risk of the overheating of electronic instruments and damage to the plastic parts of the cockpit. When parking the airplane, cover the canopy with a canopy cover.

8.1.2 Towing of the airplane

It is possible to move the airplane on the ground with a towing bar specially supplied for that, or by pushing the airplane (use “step” area of the wing to push). If it is necessary to lift the front wheel, it is possible to do so by pulling the tail skid to the ground.

8.1.3 Jacking

Since the empty weight of this aircraft is relatively low, two people can lift the aircraft easily. First of all prepare two suitable supports to support the aircraft. It is possible to lift the aircraft by handling the following parts:

- By pushing the fuselage rear section down in the place of a bulkhead the fuselage front section may be raised and then supported under the firewall.
- By holding the fuselage rear section under a bulkhead the fuselage rear may be raised and then supported under that bulkhead.
- To lift up a wing, push from underneath that wing only at the main spar area. Do not lift up a wing by handling the wing tip.

8.2 Cleaning and Care

8.2.1 Cleaning of the canopy

Detailed description of canopy cleaning is described in “Professional Maintenance for Acryl Glass Products” that is part of supporting airplane documentation.

8.2.2 Cleaning of coated parts

The surfaces of metal sheet and laminate parts have durable coating. Under normal conditions it is necessary to preserve the surface of the airplane with polishing pastes used normally for the preservation of car bodies. During regular daily maintenance clean the airplane with clean water with the possible use of a detergent suitable for car bodies. After the washing, wipe the surface of the airplane dry.

CAUTION

It is forbidden to use other solvent-based cleaning agents for the cleaning of coated parts of the airplane.

8.2.3 Cleaning of the interior

Remove the rough dirt from the cockpit by vacuum cleaning. Clean the artificial leather covers by a cloth soaked with clean water. Clean fabric covers by vacuum cleaning and by a suitable agent for wet vacuum cleaning of car seat covers.

CAUTION

It is forbidden to use other solvent-based cleaning agents for the cleaning of coated parts of the interior.

8.2.4 Care for the landing gear

In the case it gets dirty, clean the landing gear with lukewarm water with added detergent. If the wheels of the landing gear are equipped with fairings, clean them from inside by a thrust of water.

CAUTION

It is forbidden to use other solvent-based cleaning agents for the cleaning of coated parts of the landing gear.

8.2.5 Care for the propeller

The propeller and the hub must always be kept clean in order to guarantee a faultless visual inspection during the daily checks.

There is no need for any other maintenance than the daily checks.

Clear water is ideal for cleaning. You may add some washing-up liquid and use a soft sponge. The plastic surface should be polished with car polish from time to time.

CAUTION

It is forbidden to use other solvent-based cleaning agents for the cleaning of the propeller.

8.3 Servicing operating fluids

8.3.1 Filling and draining of fuel

In the case of a higher stored volume and longer storage period it is necessary to carry out a visual check of a sample for possible content of water and/or mechanical impurities every day. In normal operation during a pre-flight inspection drain sludge from the fuel tank through the drain valve of the fuel tank by draining a small amount fuel into a prepared container. Check the fuel filter visually for the content of mechanical impurities. Transport the fuel to be filled in a way that prevents its degradation by impurities or water.

The types of fuel for the operation are specified in more detail in the operation handbook for Rotax.

The following fuels may be used:

MOGAS	
European standard	EN 228 Super ¹⁾
	EN 228 Super plus ¹⁾
Canadian standard	CAN/CGSB-3,5 Grade 3 ²⁾
US standard	ASTM D 4814
AVGAS	
US standard	AVGAS 100LL (ASTM D910)

¹⁾ min. RON 95

²⁾ min. AKI 91

The AVGAS 100LL petrol, with its higher content of lead, stresses valve seats more, forms more sediments in the lubrication system and carbonates more. Use this fuel only in the event of problems with the fuel evaporation or if no other type of fuel is available.

You can find more information about the choosing of the right fuel in the valid issue of the Service Information SI-912-016.

There are no special specified procedures for the filling of the plane with fuel. Be careful not to splash the airplane's coating or canopy. After the filling, close the fuel tank well and lock it.

Use the drain valve of the fuel tank for the draining the fuel.

CAUTION

At outside air temperatures exceeding 25 °C, do not fill individual fuel tanks at more than 90 % of their maximum volume.

NOTE

Drain the fuel only in a place and into containers specified for that in order to prevent the contamination of the environment.

8.3.2 Filling of oil

When procuring, storing, filling and/or adding, check the type of oil to be used and its viscosity specifications. In order to do that, follow the instructions of the engine's manufacturer and oil producer. In the case of a higher stored quantity, check the storage period and oil samples for possible impurities. Transport and store the oil to be filled in a way that prevents its contamination.

For the lubrication of the ROTAX 912 S2 / ULS2 engine use only oils marked according to API – SG or higher. ROTAX 912 S2 / ULS2 has been filled in the factory by the Shell Advance Ultra 4 10W – 40 oil.

Filled oil quantity.....3 liters
Minimum oil quantity.....2 liters
Oil consumption.....0.06 liters/h

You can find more information for the selection of suitable lubricant in Service Information SI-912-016 latest issue.

There are no special specified procedures for the filling of the oil. Be careful not to splash it on the engine compartment or canopy. Add oil only up to the maximum level notch.

CAUTION

The replacement of the oil may only be done by a person qualified as the airplane's maintenance technician.

8.3.3 Filling of coolant

In the case of long out of service time check the coolant's expiry date. In the case of a longer-term storage, check the coolant for possible impurities before filling it.

When checking, adding or replacement of the coolant, proceed in line with the instructions specified in the operation manual for the Rotax 912 S2 / ULS2 engine. By the manufacturer the cooling system has been filled with SHERON Antifreeze Ultra G12++ (water based cooling).

Do not use waterless coolant with this aircraft.

See further instruction on applicable coolant liquids in SI-912-016 latest issue.

Transport and store the coolant in a way that prevents its contamination.

There are no special specified procedures for the filling of the coolant. Be careful not to splash it on the engine compartment or canopy. Add the coolant only up to the maximum notch.

CAUTION

The replacement of the coolant may only be done by a person qualified as the airplane's maintenance technician.

8.3.4 Brake fluid

Check the expiry date of the brake fluid in the case of for long out of service time. In the case of a longer-term storage check the liquid visually for possible water and/or impurities before filling it.

For the adding and replacement of the brake fluid we recommend use of the DOT3 HD 230 Liquid, Standards: ISO 4925 DOT3 SAEJ 1703F, FM VSS 116.

The brake fluid should be replaced in two-year intervals (see also TOM-TC-01-AMM latest issue).

CAUTION

The replacement of the brake fluid may only be done by a person qualified as the airplane's maintenance technician.

8.4 Maintenance of the battery

An acid type VARTA 12V/19Ah battery, which does not require special maintenance, has been installed in the airplane.

Routine maintenance of the battery includes the checking of the level of recharging, check of the condition of the terminals and their treatment and the cleaning of the battery's surface. When the temperatures of the surrounding air drop below 0 °C, demount the battery from the airplane and store it in a warm and dry room. In the case of longer-term storage, recharge the battery to its full capacity.

CAUTION

Carry out the recharging of the battery and its maintenance only away from the airplane.

8.5 Break in operation

8.5.1 Engine

It does not require any special anti-corrosion treatment. Only in extreme climatic conditions and after a very long time break the following measures are recommended:

WARNING

There is a risk of injury from the rotating propeller!

Preservation of the engine:

- Heat up the engine and replace the oil.
- Leave the engine running at an increased idle and with demounted air filter inject into the carburettors about 30 cm² of preservation oil, and then switch off the engine.
- Empty the float chambers.
- Coat the carburettor control with oil.
- On a cold engine blind all openings – exhaust pipe, deaeration and air filters against dirt and moisture.
- Apply preservation oil on metal parts.

De-preservation of the engine:

- Remove all blinds.
- Clean the sparking plugs.

If the preservation has been done no earlier than a year before, it is not necessary to replace the oil. After a longer break, each year repeat the preservation procedure.

8.5.2 Propeller

It does not require any special anti-corrosion treatment.

The propeller and the hub must always be kept clean in order to guarantee a faultless visual inspection during the daily checks.

Clear water is ideal for cleaning. You may add some washing-up liquid and use a soft sponge. The plastic surface should be polished with car polish from time to time.

There is no need for any other maintenance than the daily checks.

8.6 Inspections

Regular and thorough maintenance is a condition for a reliable and safe operation of the airplane. The airplane's lifetime as a whole includes the lifetimes of its key parts, which are the airframe, the engine and the propeller.

8.6.1 Airframe

Periodic inspections

Operation hours	Type of inspection	To be done by
Pre-flight inspection		Pilot or designated mechanic / technician
25 hours	After first 25 operating hours	Authorized service centre
100 hours / 1 year *	After each 100 operating hours	AMO Approved maintenance organization

* - whichever occurs first

Inspection after the first 25 hours is warranty inspection.

Handling, Service and Maintenance

In order to demonstrate continued airworthiness, the engine and airframe must be inspected after the **first** 25 hours of operation.

A periodic inspection after each 100 hours or 1 x in 12 months, whichever occurs first.

8.6.2 Rotax 912 S2 / ULS2 engine

The engine Rotax 912 S series is certified by EASA (EASA.E.121). For all Rotax 912 S2 engine related issues refer to ROTAX and TOMARK accepted documentation.

The engine Rotax 912 ULS2 series is approved with the aircraft and continued airworthiness is provided by TOMARK. For all engine related issues refer to TOMARK accepted documentation. Referenced documents this AFM and according AMM of the Viper SD-4 RTC can be considered accepted by TOMARK.

Periodic inspections of the Rotax 912 S2 / ULS2 engine

Operation hours	Type of inspection	Performed by
25 hours	After first 25 operating hours	Authorized service centre
100 hours / 1 year *	After each 100 operating hours	AMO
200 hours	After each 200 operating hours	AMO
600 hours	After each 600 operating hours	AMO
Every 5 years	Replacement of parts defined in MAINTENANCE MANUAL (Line Maintenance) for Rotax Engine Type 912 Series, latest issue Chapter 05-10-00 point 2.1) Time limits for rubber parts and point 2.2) Time limit for fuel pump	AMO
2 000 hours / 15 years *	Overhaul	Authorized ROTAX overhaul facility

* - whichever occurs sooner

Detail information about inspection can be found in the Aircraft Maintenance Manual. The aircraft Maintenance Manual uses reference to the Rotax Maintenance Manual for engine type 912 series (Ref. No. MML-912).

The engine's lifetime is specified by TBO. TBO for Rotax engine type 912 series is set 2000 hours or 15 years by engine manufacturer for engine 912 S series from S/N: 4 923 890 and for engine 912 ULS series from S/N: 6 775 790. After reaching this time limit, the engine has to be shipped to an authorized ROTAX overhaul facility.

8.6.3 Propeller NEUFORM

The propeller is approved with the aircraft and continued airworthiness is provided by TOMARK. For all propellers related issues refer to TOMARK accepted documentation. Referenced documents this AFM and according AMM of the Viper SD-4 RTC can be considered accepted by TOMARK.

Periodic inspections of the NEUFORM CR3-65 (IP) 47-101.6

Operation hours	Type of inspection	To be done by
Pre-flight inspection		Pilot or designated mechanic / technician
25 hours	After first 25 operating hours or after each new installation	Authorized service center
100 hours / 1 year *	After each 100 operating hours	AMO
2 000 hours	Propeller manufacturer factory overhaul	TOMARK (in cooperation with Neuform)

* - whichever occurs sooner

There is no life limit for the propeller. The propeller is subject of periodic inspections at the airplane manufacturer or his partner's service centre and propeller manufacturer or his authorized partner.

8.7 Maintenance of instruments and devices

Carry out the maintenance of instruments and devices in line with the instructions according to TOM-TC-01-AMM and instruction manual of respective instrument or device.

During the periodic inspections check the instruments and devices for apparent damage and damaged marking and check whether the limits specified by the instruments are sufficiently readable and in line with specified values of this AFM.

8.8 Identification of causes of faults and their elimination

During the operation of the airplane, the following faults may occur:

8.8.1 Engine

The engine will not start

<i>Possible cause</i>	<i>Solution</i>
STARTER POWER switched OFF ...	Switch the ignition ON.
FUEL selector switched OFF	Switch it to tank with more fuel.
Clogged fuel filter	Clean the fuel filter (or replace it).
Empty fuel tank	Fill it up.
The starter's RPM is low, the battery is flat	Recharge the battery.
The starter's RPM is low..... (winter period)	Use a low viscosity oil. Pre-heat the engine.
A warmed-up started to loses power	Leave it to cool down sufficiently.

After being started, the engine runs irregularly and gives out smoke

<i>Possible cause</i>	<i>Solution</i>
CHOKE switched ON.....	Switch the choke OFF

Low oil pressure

<i>Possible cause</i>	<i>Solution</i>
Too little oil in the oil tank	Check the oil level and add oil if necessary

Engine detonations

Possible cause

Solution

The engine is overheated Cool down at about 2,000 RPM

Engine rattles when loaded

Possible cause

Solution

The fuel is low-octane Fill up fuel a higher octane fuel

Difficult to start the engine at low temperatures

Possible cause

Solution

Low RPM to start Heat up the engine.

The battery is flat Recharge the battery.

High oil pressure If the gauge shows 7 bar at cold start, it does not always indicated a fault.

Too low oil pressure

after starting a cold engine Too high resistance in the suction oil piping at low temperatures.
Stop the engine and heat up the oil.

8.8.2 Propeller

Vibrations from the propeller in flight or on the ground

Possible cause

Solution

Loss of the propeller aerodynamic balance Stop engine and contact aircraft manufacturer or AMO
Check whether all propeller blades are adjusted to the correct angle.

Loss of the part of the propeller assembly Stop engine and contact aircraft manufacturer

NOTE

For propeller trouble shooting always contact TOMARK or approved maintenance organization (AMO).

8.9 Spare parts

Spare parts must be supplied with EASA Form 1 by TOMARK.

Transponder and Radio can be supplied directly (with Form 1) by f.u.n.k.e.

Dynon hardware and software (any) needs to be supplied by TOMARK POA and no direct delivery by Dynon is approved.

In specific cases the engine can be replaced directly by an approved version of the ROTAX engine (delivered with Form 1 issued by ROTAX). It means the Rotax 912 S2 engine certified by EASA (EASA.E.121). Note that TOMARK must to be contacted and approval for engine exchange must be coordinated by TOMARK.

CAUTION

The airplane's manufacturer is not liable for the damage occurred on the airplane or its units that was caused by the use of unsuitable or degraded operation filings or by the use of unsuitable, non-original parts or accessories or by non-professional interventions during its control, operation or maintenance.

Section 9

SUPPLEMENTS

This section contains the list of appropriate supplements and list of affected pages of TOM-TC-01-AFM.F document for Viper SD-4 RTC S/N: 30790 airplane necessary to safely and efficiently operate the airplane when equipped with various optional systems and equipment not provided with the standard airplane in basic configuration compliant with EASA.A.606.

Suppl. No.	Title of inserted supplement	Date	Rev. No.
	List of affected pages		
01	LANDING LIGHT	14.DEC 2018	0
	1-9, 2-8, 2-9, 2-11, 2-12, 4-5, 4-6, 4-8, 4-16, 4-17, 4-18, 7-8, 7-12, 7-15, 7-17, 7-19, 7-37, 7-38, 7-39, 7-40		

LEFTBLANK INTENTIONALLY